


Lave-linge

936020065 (SA-151) - FAGOR

(Partie 1)




0	SBM000205	KIT
2	SBM000182	CROCHET
5	SBM000356	PORTE-COMMANDES
6	SBM000355	TOUCHE
6	SBM000407	INTERRUPTEUR
8	SBM000350	COMMANDE PROGRAMMAT.

8	SBM000196	CLIP
9	SBM000359	PLAN SUPERIEUR
12	SBM000351	PROGRAMMATEUR
13	SBM000360	LAMPE
14	SBM000352	SUPPORT

Lave-linge

936020065 (SA-151) - FAGOR

(Partie 2)




15	SBM000361	PANNEAU FRONTAL	28	SBM000454	FILTRE
16	SBM000158	FERMETURE	30	SBM000172	PLINTHE
17	SBM000159	SUPPORT	31	SBM000146	JOINT
18	SBM000160	RESSORT	31	SBM000421	THERMOSTAT
19	SBM000161	TARGETTE	32	SBM000318	CONDUIT
20	SBM000162	TARGETTE	33	SBM000177	CHARNIERE ECOUTILLE
21	SBM000163	MANETTE	34	SBM037010	FREIN
22	SBM000164	COMMANDE PROGRAMMAT.	36	SBM000178	ENS. FERMETURE
23	SBM000165	CADRE	37	SBM000179	MICRORRUPTEUR
24	SBM000166	WISEUR	38	SBM000180	TARGETTE
25	SBM000167	CONTRE-CADRE	39	SBM000181	RESSORT
26	SBM000168	RESSORT	40	SBM000169	JOINT
28	SBM000171	FILTRE	41	SBM000170	CONTRE-CADRE

Lave-linge

936020065 (SA-151) - FAGOR

(Partie 3)



102	SBM000263	CLAVETTE	119	SBM000198	PIED REGLABLE
102	SBM000435	PANNEAU LATERAL	120	SBM000489	MOTEUR
103	SBM000243	COUVERTURE	121	SBM012050	TENDEUR
104	SBM000322	COUVERTURE	122	SBM105140	RESSORT
105	SBM000323	PANNEAU	122	SBM000201	RESSORT
106	SBM000187	COUSSINET	123	SBM000451	JOINT
106	SBM000464	COLLIER	124	SBM000491	COURROIE
110	SBM000325	THERMOSTAT	125	SBM000341	CUVE
111	SBM000365	BUTEE	126	SBM000343	GARDE-CABLES
112	SBM000327	RESISTANCE	127	SBM000292	BLOC
113	SBM000328	PALE VENTILATEUR	128	SBM000344	SUPPORT
113	SBM000226	PALE VENTILATEUR	130	SBM000436	CABLE ALIMENTATION
114	SBM000139	POSITIONNEUR	131	SBM000463	KIT
116	SBM017020	ROUE	133	SBM059070	GOIJON
117	SBM000197	AXE	150	SBM000190	PRISE
118	SBM000329	CONDENSATEUR	200	SBM000366	NOTICE USAGER

[illegible]