





Mat. – Nr. – Konstante
3740

Gebrauchsanweisung
59 1154
(GB,FR,ES,PT)

- 1) 17 1312
2) 42 4340
3) 43 8723
4) 49 5511
V01
49 7503
V02
5) 16 5552
6) 36 9906
7) 41 8128
8) 42 4824
9) 42 8184
10) 36 9820
11) 36 6905



Mat. – Nr. – Konstante
3740


1) 17 3747

2) 49 1361

3) 16 5557

4) 18 8194

5) 18 8188



Pos.	Danfoss		
	NLE13KK3		
1	14 3864		
2	18 1014		
3	35 4158		
4	16 3427		
5	49 4671		
6	17 1318		
7	17 1519		
8	42 0376		
9	16 5570		
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER			
Verdichter/Compressor/Kompresör Typ/Type/Tip Förderleistung/Delivery/Verim/h Anlaufstrom/Starting current/Giris akimi Widerstand/Resistance/Rezistans Ha/ Hi/aux.	Danfoss NLE13KK3 A Ohm		
Temp.Reyler/Thermostat/Termostat Typ/Type/Tip Reglerstellung/Position/Termostat pozisyonu Schaltwerte/Acta kapama degerleri Valeurs de commutation/Termostat degeri (..abtaven' od)	Elektronisch ..ein/acma °C ..aus"/kapama ..alarm'		
Füllmenge/Fill. quantily/ Dolum miktarı	R600 g	42	
Anschlusswert/Comm. load/Giris gucu	W	*	
Heizung/Heater/Rezistans Widerstand/Resistance/Direnc Leistung/Power/Guc	Ohm W		
Ventilador/Blower/Vantilatör Widerstand/Resistance/Rezistans	Ohm		
Magnetventil/Magnetic valve/Manyetik valf Widerstand/Resistance/Rezistans Spannung/Voltage/Gerilim	Ohm V		
Temp.Reyler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakınız