



Gebrauchsanweisung


52 7937
(DE,EN,FR,ES,PT)


- 1) 17 2579
2) 17 2575
3) 17 2574





- 1) 06 0083
- 2) 17 2274
- 3) 06 0115





TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS				
Verdichter/Compressor/Compresseur/Compresor		ASPERA		
Typ/Type/Tipo		NBT 1118Y		
Förderleistung/Delivery/Debit/Aspiración l/h		2574		
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A		–		
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm		11.0		
Hi/aux.		16.4		
Klappe Therm./Thermostat/Termostat				
Typ/Type/Tipo				
Reglerstellung/Position/Conexión				
Schaltwerte/Switching values/		..ein/conex.°C		
Valeurs de commutation/Desconex.		..aus"/descon.		
(..abtaven' od)		..alarm'		
Füllmenge/Fill. quantily/Charge/Carga R600		g	45	
Anschlusswert/Comm. load/Puiss. Connect./Potenc.		W	150	
Heizung/Heater/Chauflage/Resistenc.descong.		Verdampfer	Ablaufrinne	Luftkanal
Widerstand/Resistance/Resistencia		KΩ	0.38	1.4
Leistung/Power/Puissance/Potencia		W	145/230	37.5/230
Verdichter/Blower/Ventilateur/Ventilador		Verdichter	Verdampfer	
Widerstand/Resistance/Resistencia		KΩ	0.61	0.41

1) 06 0182