









Libro de instrucciones
51 9325
(D,GB,F,I,NL,S,E,DK,N,SF)

Instrucciones de montaje
51 5546
(D,GB,F,I,NL,S,E,DK,N,SF)

Juego fijación
08 4137
Juego de tornillos
08 4136





TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Danfoss		
Typ/Type		NLE 15 K		
Förderleistung/Delivery/Débit		2637		
Anlaufstrom/Starting current/Cour. de démarrage		A		
Widerstand/Resistance/Résistance		Ω		
		Hi/aux		
		Ω		
Temp.-Regler/Thermostat		Ranco		
Typ/Type		K 52-1		
Reglerstellung/Position		°C		
Schaltwerte/Switching values/		„ein“		
Valeurs de commutation		„aus“		
		„alarm“		
		Lufft.		
		max min		
		+4 +7,5		
		0 +10		
		+31,5		
		+28,5		
Füllmenge/Fill.quantity/Charge		R600a g		
		72		
Anschlußwert/Conn.load/Puiss. connectée		W		
		150		
Heizung/Heater/Chauffage				
Widerstand/Resistance/Resistance		Ω		
Leistung/Power/Puissance		W		
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance		Ω		
		Interior Exterior		
		1300 350		
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance		Ω		
Spannung/Voltage/Tension		V		

Pos.	Danfoss		
	NLE 15 K		
1	14 1311		
2			
3	15 1055		
4			
5	15 0760		
6	15 1072		
7			
8	28 1825		
9	05 0166		
10	05 9467		
11	28 6924		
12	05 6008		