




Gebrauchsanweisung

59 2594

(es,gb,de,pt)

1) 17 2293


2) 42 7532


3) 42 4340

4) 42 8184

5) 17 1312

6) 41 7908





TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS			
Verdichter/Compressor/Compresseur/Compresor	Danfoss		
Typ/Type/Tipo	NLX15KK		
Leistung/Power/Puissance/Potencia	W	181	
Anlaufstromm/Starting current/Cour.démarrage/Int.arranque	A	5,6	
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm		11,5	
	Hi/aux.	12,7	
Klape Therm./Thermostat/Termostat			
Typ/Type/Tipo			
Reglerstellung/Position/Conexión			
Schaltwerte/Switching values/	..ein/conex.°C		
Valeurs de commutation/Desconex.	..aus"/descon.		
(..abtaven' od)	..alarm'		
Füllmenge/Fill. quantily/Charge/Carga R600	g	65	
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	247	
Heizung/Heater/Chauflage/Resistenc.descong.	KW	Verdampfer	Ablaufrinne
Widerstand/Resistance/Resistencia	W	267	81
Leistung/Power/Puissance/Potencia			
Ventilador/Blower/Ventilateur/Ventilador	KW	Verdichter	Verdampfer
Widerstand/Resistance/Resistencia			

1) 17 1519

2) 16 3427