







Verdichter/Compressor/Compresseur/Compresor	DANFOSS	
Typ/Type/Tipo	NLX11KK2	
Förderleistung/Delivery/Debit/Aspiración I/h	0407	
Anlaufstromm/Starting current/Cour.démarrage/int.arranque		
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm	18,5	
Hi/aux.	31,8	
T II/QUX.	31,0	
Klape Therm./Thermostat/Termostat		
Typ/Type/Tipo		
Reglerstellung/Position/Conexión	kalt warm	
Schaltwerte/Switching values/ein/conex.°C		
Valeurs de commutation/Desconexaus"/descon.		
(abtaven' od)alarm'		
Fülmenge/Fill. quantily/Charge/Carga R600	g 50	
Anschlusswert/Comm. load/Puiss. Connect./Potenc. V	V 120	
Heizung/Heater/Chauflage/Resistenc.descong.		
Widerstand/Resistance/Resistencia K\	<b>∧</b>	
Leistung/Power/Puissance/Potencia W	/	
Ventilator/Blower/Ventilateur/Ventilador		
Widerstand/Resistance/Resistencia		