


**BOSCH**

HMG8324/01-V01, weiß
HMG8324FB/01-V02, weiß
HMG8324NL/01-V03, weiß
HMG8324GB/01-V04, weiß

HERDE
Mikrowellenherde



Mat. – Nr. – Konstante
3740

Gebrauchsanweisung
51 7123
(D,F,GB,I,NL,E)
V01,V02,V03
51 7143
(GB, 10 A)
V04

Kochbuch:
51 5732
(D)
51 5859
(NL)
51 5858
(F)
51 6251
(GB)

Zubehör:

Glaspfanne
HMZ 10GP

Alu-Backblech
HMZ 19BB

Universalpfanne
HMZ 8605

Einbaurahmen
HMZ 8022
Abdeckplatte
HMZ 8720

1) 15 0339




BOSCH

HMG8324/01-V01, weiß
HMG8324FB/01-V02, weiß
HMG8324NL/01-V03, weiß
HMG8324GB/01-V04, weiß

HERDE
Mikrowellenherde


Mat. – Nr. – Konstante
3740



**BOSCH**

HMG8324/01-V01, weiß
 HMG8324FB/01-V02, weiß
 HMG8324NL/01-V03, weiß
 HMG8324GB/01-V04, weiß

HERDE
 Mikrowellenherde



Mat. – Nr. – Konstante
 3740

- 1) 11 4538
Backblech
- 2) 11 4539
- 3) 27 3844
Universalpfanne
- 4) 03 2778
- 5) 27 1244
V01,V02,V03
27 1621
V04


02 8732
Anschlag-Backblech

**BOSCH**

HMG8324/01-V01, weiß
HMG8324FB/01-V02, weiß
HMG8324NL/01-V03, weiß
HMG8324GB/01-V04, weiß

HERDE
Mikrowellenherde

Mat. - Nr. - Konstante
3740



AET5830000086156000