


**BOSCH**

HMG8520/02-V01, weiss
 HMG8520FB/02-V02, weiss
 HMG8520NL/02-V03, weiss
 HMG8003/02-V04, weiss

HMG8520DS/02-V05, weiss
 HMG8520GB/02-V06, weiss
 HMG8520SS/02-V07, weiss
 HMG8520NL/03-V08, weiss

HERDE
 Mikrowellenherde



Mat. – Nr. – Konstante
 3740

Gebrauchsanweisung
 51 6969
 (D,F,GB,I,NL,E)
 V01,V02,V03,V04,V08
 51 7293
 (10A,D,GB,F,I,DK)
 V05,V06
 51 7401
 (S)
 V07
 Programmtabelle
 51 7597
 (DK,SS)
 V05,V07
 51 7579
 (D,GB,F,I,NL,E)
 V01,V02,V03,
 V04,V06,V08
 Kochbuch
 51 5732
 (D)
 V01,V04
 51 5858
 (F)
 V02
 51 5859
 (NL)
 V02,V03,V08

Zubehör:
 Einbaurahmen
 HMZ8122
 Alu-Backblech
 HMZ19BB
 Glaspfanne
 HMZ10GP
 Glasbräter
 HMZ21GB
 Abdeckplatte
 HMZ8720




BOSCH

HMG8520/02-V01, weiss
HMG8520FB/02-V02, weiss
HMG8520NL/02-V03, weiss
HMG8003/02-V04, weiss

HMG8520DS/02-V05, weiss
HMG8520GB/02-V06, weiss
HMG8520SS/02-V07, weiss
HMG8520NL/03-V08, weiss

HERDE
Mikrowellenherde

Mat. – Nr. – Konstante
3740




**BOSCH**

HMG8520/02-V01, weiss
 HMG8520FB/02-V02, weiss
 HMG8520NL/02-V03, weiss
 HMG8003/02-V04, weiss

HMG8520DS/02-V05, weiss
 HMG8520GB/02-V06, weiss
 HMG8520SS/02-V07, weiss
 HMG8520NL/03-V08, weiss

HERDE
 Mikrowellenherde



Mat. - Nr. - Konstante
 3740

- 1) 11 4537
Glaspfanne
- 2) 11 4539
- 3) 11 4538
Backblech
- 4) 03 2778
- 5) 27 1244
V01, V02, V03, V04,
V05, V07, V08
27 1621
V06
- 6) 27 0323
V01, V02, V03, V04,
V05, V07, V08
27 1620
V06
- 7) 09 2677
kompl.
V01, V02, V03, V04,
V05, V07, V08
09 2676
kompl.
V06

02 8732
Anschlag-Backblech


**BOSCH**

HMG8520/02-V01, weiss
 HMG8520FB/02-V02, weiss
 HMG8520NL/02-V03, weiss
 HMG8003/02-V04, weiss

HMG8520DS/02-V05, weiss
 HMG8520GB/02-V06, weiss
 HMG8520SS/02-V07, weiss
 HMG8520NL/03-V08, weiss

HERDE
 Mikrowellenherde

Mat. – Nr. – Konstante
 3740



AET5830000086053000