





Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
58 8089

- 1) 17 2579
- 2) 17 2293
- 3) 17 2256
- 4) 41 8128




Mat. – Nr. – Konstante
3740

- 1) 06 0083
- 2) 17 2274
- 3) 16 5557
- 4) 18 8194
- 5) 18 8188
- 6) 48 8448
- 7) 24 1232



Mat. – Nr. – Konstante
3740

1) 43 2966



TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS			
Verdichter/Compressor/Compresseur/Compresor	Danfoss		
Typ/Type/Tipo	NLX15 KTK		
Förderleistung/Delivery/Debit/Aspiración l/h			
Anlaufstromm/Starting current/Cour.démarrage/Int.arranque A			
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm			
Hi/aux.			
Klappe Therm./Thermostat/Termostat			
Typ/Type/Tipo			
Reglerstellung/Position/Conexión			
Schaltwerte/Switching values/	..ein/conex.°C		
Valeurs de commutation/Desconex.	..aus"/descon.		
(..abtaven' od)	..alarm'		
Füllmenge/Fill. quantily/Charge/Carga R600	g		
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W		
Heizung/Heater/Chauflage/Resistenc.descong.			
Widerstand/Resistance/Resistencia	KΩ		
Leistung/Power/Puissance/Potencia	W	81	4
Ventilador/Blower/Ventilateur/Ventilador		Verdampfer	
Widerstand/Resistance/Resistencia	KΩ		

Mat. – Nr. – Konstante
3740