





Mat. – Nr. – Konstante
3740

Gebrauchsanweisung

52 9650
(de,en,fr,it,nl,
el,,es,pt,ru,tr)


- 1) 17 2762
- 2) 17 2579




Mat. – Nr. – Konstante
3740

- 1) 17 2274
- 2) 06 0115

Mat. – Nr. – Konstante
3740





TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS			
Verdichter/Compressor/Compresseur/Compresor	ASPERA		
Typ/Type/Tipo	NBU 1118Y		
Förderleistung/Delivery/Debit/Aspiración l/h			
Anlaufstromm/Starting current/Cour.démarrage/Int.arranque A	—		
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm	13.6		
Hi/aux.	14.7		
Klape Therm./Thermostat/Termostat			
Typ/Type/Tipo			
Reglerstellung/Position/Conexión	kalt	warm	
Schaltwerte/Switching values/ ..ein/conex.°C			
Valeurs de commutation/Desconex. ..aus"/descon.			
(..abtaven' od) ..alarm'			
Füllmenge/Fill. quantily/Charge/Carga R600	g	45	
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	150	
Heizung/Heater/Chauflage/Resistenc.descong.		Verdampfer	
Widerstand/Resistance/Resistencia	KΩ	0.375	
Leistung/Power/Puissance/Potencia	W	145/230V	
Ventilator/Blower/Ventilateur/Ventilador	Verdichter	Verdampfer	
Widerstand/Resistance/Resistencia	KF 0.57	GF 0.47	

Mat. – Nr. – Konstante
3740