


Mat. – Nr. – Konstante
3740

Gebrauchsanweisung

52 9650


(de,en,fr,it,nl
el,es,pt,tr)

58 0519

(da,no,sv,fi,
ro,hu,pl,ru)


1) 17 2579

2) 17 2762




Mat. – Nr. – Konstante
3740

- 1) 17 2274
- 2) 06 0115
- 3) 06 0083
- 4) 18 8194
- 5) 18 8188



Mat. – Nr. – Konstante
3740



TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS			
Verdichter/Compressor/Compresseur/Compresor Typ/Type/Tipo Förderleistung/Delivery/Debit/Aspiración l/h Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm Hi/aux.	ASPERA NBU 1118Y — 13.6 14.7		
Klappe Therm./Thermostat/Termostat Typ/Type/Tipo Reglerstellung/Position/Conexión Schaltwerte/Switching values/ ..ein/conex.°C Valeurs de commutation/Desconex. ..aus"/descon. (..abtaven' od) ..alarm'	kalt warm		
Füllmenge/Fill. quantily/Charge/Carga R600 g	45		
Anschlusswert/Comm. load/Puiss. Connect./Potenc. W	150		
Heizung/Heater/Chauflage/Resistenc.descong. Widerstand/Resistance/Resistencia KΩ Leistung/Power/Puissance/Potencia W	Verdampfer 0.375 145/230V		
Ventilator/Blower/Ventilateur/Ventilador Widerstand/Resistance/Resistencia	Verdichter KF 0.57	Verdampfer GF 0.47	

Mat. – Nr. – Konstante
3740

1) 06 0182