





Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
59 1267

- 1) 17 2579
- 2) 17 2293
- 3) 17 3845
- 4) 41 8169
- 5) 42 1602
- 6) 42 4340




Mat. - Nr. - Konstante
3740

- 1) 17 3862
- 2) 17 2274
- 3) 42 1440
- 4) 18 8194
- 5) 18 9083
- 6) 49 1355
- 7) 42 4562



Mat. – Nr. – Konstante
3740

1) 43 2396
V01



TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS			
Verdichter/Compressor/Compresseur/Compresor Typ/Type/Tipo Förderleistung/Delivery/Debit/Aspiración l/h Anlaufstromm/Starting current/Cour.démarrage/Int.arranque A Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm Hi/aux.	Danfoss NLE15 KTK2		
Klappe Therm./Thermostat/Termostat Typ/Type/Tipo Reglerstellung/Position/Conexión Schaltwerte/Switching values/ ..ein/conex.°C Valeurs de commutation/Desconex. ..aus"/descon. (..abtaven' od) ..alarm'	RANCO K59/p1777 +3.5 +3.5 -31 -21		
Füllmenge/Fill. quantily/Charge/Carga R600	g	65	
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	247	
Heizung/Heater/Chauflage/Resistenc.descong. Widerstand/Resistance/Resistencia Leistung/Power/Puissance/Potencia	KΩ W	267	81 4
Ventilador/Blower/Ventilateur/Ventilador Widerstand/Resistance/Resistencia	KΩ	Verdichter	Verdampfer

Mat. – Nr. – Konstante
3740