




Mat. – Nr. – Konstante
3740

Gebrauchsanweisung

58 7344

(de,en,fr,it,nl
pl,tr,es,pt)

58 7345

(da,no,sv,fi,
ro,hu,el,ru)

1) 17 2762

2) 17 2579


3) 06 0086

4) 42 3890

5) 18 4304

6) 42 1434


7) 42 0860




Mat. – Nr. – Konstante
3740

- 1) 06 0083
- 2) 17 2274
- 3) 42 4949
- 4) 18 8194
- 5) 18 8188

Mat. – Nr. – Konstante
3740





TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS				
Verdichter/Compressor/Compresseur/Compresor	ASPERA			
Typ/Type/Tipo	NBT 1118Y			
Förderleistung/Delivery/Debit/Aspiración l/h	2574			
Anlaufstromm/Starting current/Cour.démarrage/Int.arranque A	—			
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm	11.0			
Hi/aux.	16.4			
Klappe Therm./Thermostat/Termostat				
Typ/Type/Tipo				
Reglerstellung/Position/Conexión				
Schaltwerte/Switching values/	..ein/conex.°C			
Valeurs de commutation/Desconex.	..aus"/descon.			
(..abtaven' od)	..alarm'			
Füllmenge/Fill. quantily/Charge/Carga R600	g	45		
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	150		
Heizung/Heater/Chauflage/Resistenc.descong.		Verdampfer	Ablaufrinne	Luftkanal
Widerstand/Resistance/Resistencia	KΩ	0.38	1.4	13.49
Leistung/Power/Puissance/Potencia	W	145/230	37.5/230	4/230
Ventilador/Blower/Ventilateur/Ventilador		Verdichter	Verdampfer	
Widerstand/Resistance/Resistencia	KΩ	0.61	0.41	

Mat. – Nr. – Konstante
3740