







Mat. – Nr. – Konstante
3740

Gebrauchsanweisung
52 5501
(E,GB)


Montagegeanleitung
52 1893
(D,GB,F,I,NL,S,E,DK,N,,SF)

Befestigungssatz
26 7361

Mat. – Nr. – Konstante
3740



Mat. – Nr. – Konstante
3740



Pos.	Danfoss		
	NLY 13K		
1	14 1747		
2			
3	15 1055		
4			
5	15 1053		
6	15 1072		
7			
8	28 1825		
9	05 0166		
10	05 9467		
11	26 6624		
12	05 6008		

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Danfoss		
Typ/Type		NLY 13 K		
Förderleistung/Delivery/Débit		l/h	2637	
Anlaufstrom/Starting current/Cour. de démarrage		A	11,3	
Widerstand/Resistance/Résistance		Ha/main/prin. Ω	11,0	
		Hi/aux Ω	9,0	
Temp.-Regler/Thermostat		RCO K59		
Typ/Type		KER		
Reglerstellung/Position		kalt warm		
Schaltwerte/Switching values/ Valeurs de commutation		„ein“ $^{\circ}\text{C}$	+4,5	+4,5
		„aus“ („abtauen“ od.) „alarm“	-32,0	-21
Füllmenge/Fill.quantity/Charge		R600a	g	*
Anschlußwert/Conn.load/Puiss. connectée		W	150	
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance		Ω		
Leistung/Power/Puissance		W		
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance		Ω		
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance		Ω		
Spannung/Voltage/Tension		V		

* siehe Typenschild