







Gebrauchsanweisung
58 8897
(de,en,fr,it,es,pt,gr)
Montageanleitung
58 8057
Beistellsatz
49 1366
Listerien Rep.Satz
41 7589



Mat. – Nr. – Konstante
3740



Pos.	V01		
	Aspera		
	EMY26CLC		
1	14 3828		
2			
3	41 7964		
4			
5	17 0882		
6	17 0881		
7			
8	35 5493		
9	05 0166		
10	41 8628		
11	26 6624		
12	05 6008		

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Aspera		
Typ/Type		EMY26CLC		
Förderleistung/Delivery/Débit		l/h	938	
Anlaufstrom/Starting current/Cour. de démarrage		A	0,7	
Widerstand/Resistance/Résistance		Ha/main/prin. Ω	28,5	
		Hi/aux Ω	43,3	
Temp.-Regler/Thermostat				
Typ/Type				
Reglerstellung/Position				
Schaltwerte/Switching values/		„ein“ $^{\circ}\text{C}$		
Valeurs de commutation		„aus“		
		(„abtauen“ od.) „alarm“		
Füllmenge/Fill.quantity/Charge		R600a g		
Anschlußwert/Conn.load/Puiss. connectée		W	53	
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance		Ω		
Leistung/Power/Puissance		W		
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance		Ω		
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance		Ω		
Spannung/Voltage/Tension		V		
NTC Widerstand 1%				