


BOSCH

Maxx - WFL1600EE/01-V01
Maxx - WFL1600EE/02-V02
Maxx - WFL1600EE/06-V03
Celebrity - WFL160CEE/06-V04

LAVADO
Lavadoras



Instrucciones de uso +
Instrucciones de montaje +
Tabla de programas

52 31 56
(es,pt)
V01
52 6454
(es,pt)
V02, V03
52 9580
(es,pt)
V04

Tapa metálica - VDE
21 5174

Tapa superior 3 cm.
21 5337