




BOSCH

Maxx – WFL2060EE/01–V01
Maxx – WFL2060EE/05–V02

LAVADO
Lavadoras



Instrucciones de uso +
Instrucciones de montaje +
Tabla de programas
52 3154
(ES,PT)
V01
52 6455
(ES,PT)
V02
52 3959
(DE)
V01,V02

Tapa metálica – VDE
21 5174


Tapa superior 3 cm.
21 5337




BOSCH

Maxx – WFL2060EE/01–V01
Maxx – WFL2060EE/05–V02

LAVADO
Lavadoras





1) 26 5964

