




BOSCH

Maxx – WFL2460EE/01–V01
Maxx – WFL2460EE/05–V02

LAVADO
Lavadoras




Instrucciones de uso +
Instrucciones de montaje +
Tabla de programas
52 3157
(ES,PT)
V01
52 6457
(ES,PT)
V02
52 3791
(DE)
V01,V02

Tapa metalica – VDE
21 5174

Tapa superior 3 cm.
21 5337

AET58300000083028000






BOSCH

Maxx – WFL2460EE/01–V01
Maxx – WFL2460EE/05–V02

LAVADO
Lavadoras



1) 26 5964

