





**BOSCH**

WFM3010-WFM3010/01-D1
WFM3010-WFM3010FG/01-FG1
WFM3010-WFM3010II/01-II
WFM3010-WFM3010DS/01-DS1

WFM3010-WFM3010CH/01-CH1
WFM3010-WFM3010SN/01-SN1

WASCHGERÄTE
Waschvollautomaten

Ident – Nummern – Konstante
3740




**BOSCH**

WFM3010-WFM3010/01-D1
WFM3010-WFM3010FG/01-FG1
WFM3010-WFM3010II/01-II
WFM3010-WFM3010DS/01-DS1

WFM3010-WFM3010CH/01-CH1
WFM3010-WFM3010SN/01-SN1

WASCHGERÄTE
Waschvollautomaten

Ident – Nummern – Konstante
3740



**BOSCH**

WFM3010-WFM3010/01-D1
WFM3010-WFM3010FG/01-FG1
WFM3010-WFM3010II/01-II
WFM3010-WFM3010DS/01-DS1

WFM3010-WFM3010CH/01-CH1
WFM3010-WFM3010SN/01-SN1

WASCHGERÄTE
Waschvollautomaten

Ident - Nummern - Konstante
3740

