










F2.254






F4-311



F5-100



F6-015

Pos.	Reference	Description
	87X5866	INSTRUCTIONS FOR USE--FGBDNLEPD
110	79X7435	SIDE, CLADDING
111	94X3441	ATTACHMENT
115	74X0492	REAR COVER
116	79X7766	UPPER COVER
123	79X7653	BOTTOM PANEL
138	74X9173	RIGHT COLUMN
138	74X9174	LEFT COLUMN
160	76X7871	CABLE GRIP
162	79X7775	SEAL
164	79X7453	OVEN HEARTH
166	74X0346	WAVE GUARD
280	79X7440	GLASS DISH/PLATE
282	79X7439	GRID
285	75X1361	CLIP
291	75X3676	GRILL SUPPORT
293	79X7438	SHELF SUPPORT
302	74X9509	DOOR, GLASS
303	74X9085	TOP DOOR CONN BLOCK
305	79X7774	SPACER
308	74X7219	SPACER
310	74X9142	STAINLESS STEEL HAND
316	74X0901	HANDLE ATTACH SCREW
320	74X0493	DOOR BACK
335	79X7442	SEAL
340	76X2299	BOX
341	75X1465	MICROSWITCH
345	79X7468	LH HINGE
345	79X7469	RH HINGE
346	75X1468	DISASSEMBLY HOOK
352	79X7461	COOLING FAN
355	79X9449	LIMITER
356	79X7463	COOLING FAN
361	76X1618	RIGHT DOOR SAFETY DE
363	74X0432	LOCK BOLT
365	79X8002	HOLDER
366	76X5157	CLIP
367	76X1723	2 TERMINAL DOOR SWIT
368	76X1724	3 TERMINAL DOOR SWIT
401	74X9271	STAINLESS STEEL ICE
402	79X8385	STRIP SPT
405	74X8906	SMALL BAR
410	74X2979	CONTROL INDICATOR
425	71X7948	FUSE HOLDER
429	75X0120	FUSE
430	74X9510	DISPLAY CARD
435	74X0435	POWER CARD
436	77X8571	HOLDER
584	79X8023	SKIRT
585	79X7778	LAMP
586	76X1728	BULB
592	71X1930	CABLE GRIP
593	76X2328	CORD, MAINS
594	74X3536	FILTER NOISE
600	79X7454	MAGNETRON
602	79X7768	WAVE DEFLECTOR
603	79X7776	WAVE DEFLECTOR
610	79X7455	MOTOR
612	79X7770	CENTER PUNCH
616	79X7807	WAVE DEFLECTOR
617	75X2432	PULLEY
619	75X2434	BELT
620	79X7465	VALVE
622	74X0438	GRILL, AERATION
630	79X7718	TRANSFORMER
632	74X0439	HIGH VOLTAGE WIRE
633	74X0440	HIGH VOLTAGE WIRE
645	79X7452	CAPACITOR