




DE'LONGHI INT/A/RU/SKA EC400F EX:C 0132104066

Pos.	Spare part code	Description
001	5532106900	COVER
002	5332107900	MEASURING SPOON
003	5532109600	KNOB
004	5332122600	COVER
005	512302	WARNING LIGHT
006	512353	Red Warning Light
007	5932107300	CONTROL PANEL
008	611905	SPRING
009	5532106200	KNOB
010	ES000	*NOT AVAILABLE
010	512641	WARNING LIGHT
011	5132102200	Change Over Switch
012	607529	BRACKET
013	7332135500	TAP
014	511816	FUSE
015	5232101300	THERMOSTAT 125°
016	5232100600	THERMOSTAT 105°
017	536281	TUBE
018	9810153031	SCREW
019	6032103100	BOILER UPPER
020	9816100523	NUT
021	533216	GASKET
022	5132109900	HEATING Element
023	6032107100	DIFFUSER
024	5332140900	GASKET
025	7313270759	SUPPORT
026	9850081500	WASHER
027	7032103600	CONNECTION

DE'LONGHI INT/A/RU/SKA EC400F EX:C 0132104066

Pos.	Spare part code	Description
028	5313217701	O-RING D=3,85
029	6132101300	SPRING
030	534710	GASKET
031	6132101400	SPRING
032	5332118000	TUBE
033	VT205651	FILTER
034	535926	TUBE
035	534848	SUPPORT
036	5132106900	PUMP
037	5532112000	TUBE
038	7332128100	VALVE
039	5332113500	HINGE
040	5332116100	TUBE
041	6132101000	SPRING
042	7313270749	BOILER LOWER
043	7332160100	TANK
045	5332148400	VALVE
046	621986	RING
047	7032103900	DOWEL
048	6032101600	BRACKET
049	6132101600	SPRING
050	5332149900	TUBE UPPER
051	5313217761	O-RING
052	5332113800	TUBE LOWER
053	536373	GASKET
054	5332229600	COVER
055	5332131300	CONNECTION H2O
056	5332117200	PRESSING DEVICE

DE'LONGHI INT/A/RU/SKA EC400F EX:C 0132104066

Pos.	Spare part code	Description
057	5332118600	INSERT
058	7032102400	CUP PLATE
059	5332130000	TRAY
060	532233	RUBBER PAD
063	5532106300	BOTTOM
064	533921	WIRE CLAMP
065	5332122500	BODY
066	5332108700	GASKET
067	5332109000	PISTON
068	6132100800	SPRING
069	5332111600	O-RING
070	7313279579	SUMP
071	5332123100	RING NUT
072	6032107300	FILTER
074	534714	LEVER
075	7332173800	Large two-cup filter

Spare parts list extract from the site on 09-12-2010