




DE'LONGHI INT/SA/RU/SKA EC9 0132007032

Pos.	Spare part code	Description
01	T12000BLC	BODY
02	T12001BLC	COVER
03	T12002WHLSPDL1	FRONT PIECE
04	T12005BKSDL1	COVER
05	611905	SPRING
07	T11816BKS	KNOB
08	535875	SUPPORT
09	T67109	RING
10	611900	SPRING
11	5532103000	KNOB
12	537159	STOPPER
13	537200	CONNECTION
14	535747	WIRE CLAMP
15	T12003BLC	BOTTOM
16	532233	RUBBER PAD
17	T12004BKS	CUP PLATE
18	512441	SWITCH
19	ES000	*NOT AVAILABLE
20	535592	LENS
21	5532112600	REGULATOR
22	5332100500	TUBE
23	536372	GASKET
24	535692	O-RING
25	5332102100	MIXER
26	738656	TRAY
27	5332100600	CAP
28	5332107900	MEASURING SPOON
29	736373	STOPPER

DE'LONGHI INT/SA/RU/SKA EC9 0132007032

Pos.	Spare part code	Description
30	535695	GASKET
31	511816	FUSE
32	VI000	SEE TECNICAL INFORMATION
33	534714	LEVER
34	607604	FILTER
35	537009	ADAPTER
36	736376	TAP
37	535696	GASKET
38	622156	BODY
39	T67108	O-RING
40	738653	TAP
41	535749	TUBE
42	535750	GASKET
43	6932100100	DISTRIBUTOR
44	T67106	GASKET
45	690335	DIFFUSER
46	T35110	BOILER LOWER
47	537010	COVER
A	T34150	FILTER
B	T34211	CARAFE ASSMBLY

Spare parts list extract from the site on 04-08-2010