





DE'LONGHI
SA INT IR XVT3000

Pos.	Code	Description
001	5393127200	STOPPER
002	5993106200	TEMPLATE
005	5393505900	GASKET
006	5393507700	INSULATOR
007	5393123200	SUPPORT
008	VT138055	PRESSURE Switch
009	6293100000	CONNECTION
010	5291101100	SOLENOID VALVE
011	5393503400	GREEN LENS
012	VT128309	RED LENS
013	5393506300	TUBE
014	5193104400	SWITCH
015	5193102300	LAMP
017	5093101300	POWER SUPPLY CORD
018	5393122800	REAR CASTOR
019	5393136700	PROTECTION LH
020	5319310221	SUPPORT
023	5391131600	FRONT CASTOR
024	6191101700	PIN
032	5393129400	WIRE CLAMP
036	5393136600	PROTECTION RH
038	5393506400	TUBE
039	5393126600	TANK
043	VT109714	CAPACITOR 0,33uF
044	5393126300	COUPLING
046	5393126400	SUPPORT
047	5191105900	PUMP
048	5191103700	BOARD
049	VT106349	BRACKET
050	5291101600	TCO 216°
052	5393506500	TUBE
053	5328501000	CONNECTION
054	5328500900	O-RING
055	5528103200	VALVE
056	5328502800	O-RING
057	5312812571	HOSE COUPLING
058	9816100626	NUT

DE'LONGHI

SA INT IR XVT3000

059	5393506200	TUBE
060	9824820111	CLIP CLAMP
062	7393124500	BOILER KIT
063	607444	BRACKET
064	5291101400	THERMOSTAT 175
065	5291101300	THERMOSTAT
067	7393120100	FLEXIBLE TUBE
068	5393127400	PROTECTION LH
069	6193102700	SPRING
070	5393128300	LEVER
073	5393128900	COUPLING
074	VT107446	GASKET
075	5393123900	PUSH BUTTON
076	6193100400	SPRING
077	5393127300	PROTECTION RH
078	5393505300	TUBE
079	5393121500	COUPLING
080	SC26000040	BALL
082	6193102800	SPRING
084	5093508400	MICROSWITCH
085	5393127500	PROTECTION Upper
086	5393502000	O-RING
087	5393121400	COUPLING
089	5593110000	SHEATH
090	5393123100	PROTECTION
092	5393505400	TUBE
094	5393123100	PROTECTION
100	5393127600	PROTECTION LOWER
101	7393132900	EXTENSION
104	5393124400	RUBBER
106	7393120200	SQUEEGEE
107	7393119700	SPRAYER
108	VT538561	BLACK BRUSH
109	5593107500	BRUSH
110	7393119900	BRUSH
111	VT106016	CLOTH
112	VT538565	BRUSH