


SPAREPARTLIST

Pos	12NC	Description
0252	4812 460 79187	Trim lower
0400	4810 105 62919	Hinge 2 glass w/o spring
0401	4810 105 62918	Hinge 2 glass with spring
0470	4810 105 02060	Hinge support
1100	4810 107 19542	Handle
1101	4812 466 68928	Buffer piece door handle
1102	4812 462 48451	Washer door handle
1213	4810 105 20988	Deflector
1300	4810 105 18426	Door lock
1410	4810 107 74843	Oven glass + supports
1420	4810 105 45250	Inner glass
1431	4810 105 05592	Support glass right
1433	4810 105 05361	Support glass left
1910	4810 106 04774	Gasket door oven
2010	4810 107 64525	Cover rear grey
2450	4810 106 57433	Grid Oven Vulcano
2460	4810 107 64531	Baking tray grey
2610	4810 106 57448	Insert grid
3010	4810 107 63615	Knob
3340	4810 107 18374	Knob
3510	4801 310 00099	Kit Pilot lamp
3540	4819 462 79749	Lens red
4400	4812 361 18492	Motor fan
4410	4801 211 03444	Fan assembly
4430	4819 515 48065	Fan 6-blades
4510	4812 259 98406	Heating element forced-air 2000W 230V
4520	4812 259 98472	Heating element soft grill
4560	4810 103 75734	Heating element lower
4901	4801 211 04772	Cable clamp
4902	4812 316 18036	Cover cable
4910	4812 290 68329	Connection block
5032	4810 106 57893	Clock 180' mechanical
5540	4801 211 00077	Thermostat
5570	4810 105 52514	Thermostat 285 °C
5572	4812 282 28282	Temper.limiter
6200	4810 105 00994	Selector switch oven FY14 MF6
6510	4810 103 91431	Oven lamp halogen 40W
6520	4810 106 38530	Halogen lamp complete assembly 40W
6560	4810 106 46361	Glass cover
9150	4819 505 18145	Nut fan motor
9300	4812 404 18649	Clamp fixation thermostat
9930	4812 310 39061	Spacer

IMAGE EXPLODED VIEW



4000 107 84095