

PARTS LIST

SAFETY PRECAUTION

Parts identified by the $\triangle$ symbol are critical for safety. Replace only with specified part numbers.

BEWARE OF BOGUS PARTS


Parts that do not meet specifications may cause trouble in regard to safety and performance. We recommend that genuine JVC parts be used.

1. EXPLODED VIEW

1.1 FINAL ASSEMBLY<M1>

The instruction manual to be provided with this product will differ according to the destination.

UPPER ASSEMBLY



MODEL	MARK	MODEL	MARK	MODEL	MARK
GZ-MG155EK	A	GZ-MG155EZ	D	GZ-MG175EZ	G
GZ-MG155EX	B	GZ-MG175EK	E		
GZ-MG155EY	C	GZ-MG175EY	F		

2. PARTS LIST

FINAL ASSEMBLY <M1>

△ Symbol No.	Part No.	Part Name	Description	Local
301	LY21554-001D	MONI CASE		
302	LY21555-001A	BUTTON(MONI)	(x2)	
303	LY21556-001B	LCD CASE		
304	LY35825-001A	LCD BKT ASSY		
305	LY35476-001A	SPACER(LCD)		
306	LY35477-001A	SPACER(LCD-2)		
307	QLD0486-001	LCD MODULE		
308	LY35478-001A	SHEET(BEF)1		
309	LY35479-001A	SHEET(BEF)2		
310	LY35480-001A	SHEET(M/DIFF)		
311	LY35481-001A	SHEET(M.REF)		
312	LY35482-001A	LIGHT GUIDE		
313	LY21561-008D	MONI COVER ASSY		
314	LY21564-001B	KNOB(CURSL)		
320	LY21558-001D	HINGE UNIT		
321	LY21559-006A	HINGE COVER(U)		
322	LY21560-001A	HINGE COVER(L)		
323	LY45427-001A	P.C.MAGNET		
324	QAL0905-002	FPC		
325	LY30031-0E3A	SPECIAL SCREW	H.CVR-HING	
330	LY21565-001F	U.CASE ASSY		
331	QAS0495-001	SPEAKER		
332	LY35490-001B	BKT(SPEAKER)		
334	LY30034-0W4A	SPACER(A)		
340	LY30031-0L8B	SPECIAL SCREW	MON.P-M.CA(x2)	
341	LY30031-0L8B	SPECIAL SCREW	M.CO-M.CA(x2)	
342	LY30031-062A	SPECIAL SCREW	M.CO-HING(x2)	
343	LY30031-039A	SPECIAL SCREW	B.SPK-UPR(x2)	
344	LY30031-0M6A	SPECIAL SCREW	HING-UPR(x2)	
345	LY30031-0L8B	SPECIAL SCREW	OPE.P-UPR(x4)	