

## Exploded view of general assembly and parts list





The parts without symbol number are not service.

## CD mechanism assembly and parts list

Block No. M B M M FMU-CD4-11D Grease (42) ★ JVG-31N ▲ FG-87HS JVS-1003 Photo board Rest switch board В 62 (30) (44) Back side 🚽 (35) 5 (3) (7) (37) (38) 11.1mm±0.1mm 1 Ė Mecha control board 63) 11.1mm±0.1mm **★**(13) (11) (15) The parts without symbol number are not service.