

Exploded view of general assembly and parts list

Block No. M 1 M M 141 (42) (140) 75 76 (89) (143) (156) (152) 142 (155) g 66 Main board 66 Sub board Except EE ver. 66 68) 64 63 (41) 67 92 g 49 [67) 64) (70) 61) Only J ver. 83 (137) (136) (137) (126) 105 65 138 160 60 103 62 62 (103) 62 Panel board 103 103 103 118 103 (125) (101) (116) (102) 103 (103) (119) (125) 125 Q 124 123 (117) 26) (104) 133 (120) (135) 116 (118) 97 (132) 94) (125) (131) 122 123 95 122 115 129 R (125)



The parts without symbol number are not service.

DVD mechanism assembly and parts list




The parts without symbol number are not service.

Packing materials and accessories parts list

Block No. M 3 M M

No additional / supplemental order of WARRANTY CARDs are available.



The parts without symbol number are not service.