

Welcome to Kenwood Food Preparation

Your new Kenwood Food Mixer will make food preparation a simple and enjoyable task. To reap maximum benefit from your mixer keep it ready to use on a convenient worktop for whenever you need it. A large range of attachments is available which will enable you to explore further culinary delights. (Please note some attachments are for special international markets only.)

Connecting to Power

Before switching on make sure that the voltage of your electricity supply is the same as that indicated on the rating plate.


IMPORTANT (UK ONLY): The wires in the mains lead are coloured in accordance with the following code:

BLUE	NEUTRAL
BROWN	LIVE

Important Note: This appliance complies with European Economic Community Directive 89/336/EEC

KEY

1 Planetary Drive/Beater socket	Attachments	Model	Attachments	Model
2 Slow Speed Outlet	16 Kebbe Maker	A937	30 Colander and Sieve (For models KM200, KM201 & KM220)	A992
3 Slow Speed Locking Catch	17 Pasta Extruder	A936	Colander and Sieve (For models KM230&KM250)	A930
4 Juice Extractor Outlet	18 Slow Speed Slicer/Shredder	A948	31 Stainless Steel Bowl (For models KM200, KM201, KM210 & KM211)	18749
5 High Speed Outlet	19 Coffee Grinder	A979	Stainless Steel Bowl (For models KM230&KM250)	18748
6 On/Off and Speed Control Switch	20 Grain Mill	A941	32 Splashguard and Flap (For models KM201, KM200, KM220, KM230 & KM250)	31225/31226
7 Body	21 Cream Maker	A927	Splashguard (For models KM210, KM211 & KM202)	30238
8 Mixer Head Release Catch	22 Can Opener	A978	33 Cover (For models KM200, KM201, KM210, KM211 & KM220)	29022
9 Bowl	23 Bean and Peel Slicer	A932		
Attachments	24 Juice Extractor	A995		
10 K Beater	25 Liquidiser	A989/A990		
11 Dough Hook (For Models KM201, KM200, KM210, KM211 & KM220)	26 Spice Mill	A938		
12 Dough Hook (For Models KM230 & KM250)	27 High Speed Slicer/Shredder	A929		
13 Whisk	28 Continuous Juice Separator	A935		
14 Mincer	29 Potato Peeler (For models KM200, KM201, KM210, KM211 & KM220)	A934		
15 Sausage Adaptor	Potato Peeler (For models KM230&KM250)	A752		



Your Mixer and Attachments

