




Libro de instrucciones
58 0143
(es,pt)



- 1) 16 2577
- 2) 03 4102
- 3) 18 2746





- 1) 41 9194
V01
41 9193
V02
- 2) 06 7938
V01
06 7929
V02
- 3) 16 2224
V01
15 2684
V02
- 4) 06 7935
V01
06 7927
V02

Cjtos transformación:
Gas Butano
15 3164
Gas Natural
15 3165