


Libro de instrucciones 52 8434 (es,pt)






27 4895



06 6063 08 9257 20 5428 23 1365 20 9862 20 5936 06 8565 **@** 08 9257 20 9863 **@** 03 3804 06 8567 **@** 06 4374 06 6063 **(**0. ,o. 20 8500 03 3538 20 6696 06 4371 35 3940 03 3538 03 3538 23 1365 27 5472 03 3538





- 1) 03 4224
- 2) 03 4232
- 3) 03 4231
- 4) 03 4223
- 5) 03 4220
- 6) 17 1714

15 3166

Cjtos. de transformac.: Gas Butano 15 3164 Gas Natural 15 3165 Gas Ciudad