

This exploded view diagram illustrates the assembly of a microwave oven. The components are labeled with the following numbers:

- 510: Control panel
- 10, 14, 14a: Control knobs
- 14b, 14d: Control panel mounting hardware
- 586, 587: Control panel mounting hardware
- 34: Microwave oven body
- 162: Control panel connector
- 37: Microwave oven door
- 157: Microwave oven door frame
- 796: Microwave oven door window
- 722: Microwave oven door latch
- 79: Microwave oven door hinge
- 700: Microwave oven base
- 614: Control panel connector
- 152, 618, 618a, 620: Control panel connector
- 680: Control panel connector
- 509: Control panel connector
- 151, 420: Control panel connector
- 782: Control panel connector
- 151: Control panel connector
- 491: Control panel connector
- 164: Control panel connector
- 482: Control panel connector
- 547: Control panel connector
- 677: Control panel connector
- 76: Control panel connector

Dibujo despiece tambor y motor

Secadoras

