


EXPLODED VIEW



REPLACEMENT PARTS LIST

Ref. No.	Part No. ER140	Part No. ER141	Part Name & Descriptions	Per set	Remarks
1	WER9199Y	WER9139Y	BLADE BLOCK	1	
2	WER140H3058	WER141H3058	HOUSING A	1	
3	WER140H3068	WER140H3068	HOUSING B	1	
4	WER140L1008	WER140L1008	MOTOR	1	
5	WER140H3208	WER140H3208	SWITCH HANDLE	1	
6	WER720W0167	WER720W0167	BLADE MOUNTING SPRING	2	
7	WER73346137	WER73346137	HOUSING SCREW	2	
8	WER395W9307	WER395W9307	SCREW FOR MOTOR	2	
9	WER140L2128	WER141L2128	MODULE	1	
10	WER140L2508	WER140L2508	RECHARGEABLE BATTERY	1	
11	WER140H0558	WER141H0558	PLUG COVER	1	
11	WER140H0560	—————	PLUG COVER	1	for U.K.
12	WER140L2108	WER141L2108	MODULE & BATTERY BLOCK	1	
13	WER140K7664	WER140K7664	ADAPTOR	1	
13	WER140K7660	—————	ADAPTOR	1	for U.K.
14	WER140K2058	WER140K2058	POWER CORD	1	
15	WER140K7398	WER140K7398	COMB ATTACHMENT A	1	
16	WER140K7408	WER140K7408	COMB ATTACHMENT B	1	
17	WER392W7087	WER392W7087	CLEANING BRUSH	1	
18	WER398B7918	WER398B7918	OIL	1	
19	—————	WER392W7157	PROTECTIVE CAP	1	
—	WER140H8008	WER141H8008	INDIVIDUAL BOX	1	
—	WER140H8010	—————	INDIVIDUAL BOX	1	for U.K.
—	WER140H8108	WER141H8108	OPERATING INSTRUCTIONS	1	