


EXPLODED VIEW



REPLACEMENT PARTS LIST

Ref. No.	Part No. ER203	Part No. ER204	Part Name & Descriptions	Per set	Remarks
1	WER964Y	WER964Y	BLADE BLOCK	1	
2	WER203K6008	WER203K6008	HOUSING SCREW	3	
3	WER300R0167	WER300R0167	SPRING FOR BLADE	2	
4	WER203K3058	WER204K3058	HOUSING A	1	
5	WER203K3068	WER204K3068	HOUSING B	1	OTHERS
5	WER203K3069	WER204K3069	HOUSING B	1	SCANDINAVIA
5	WER203K3070	WER204K3070	HOUSING B	1	UK/E. EUROPE
6	WER203K3268	WER203K3268	LOCK RELEASE BUTTON	1	
7	WER550V0197	WER550V0197	SPRING FOR BUTTON	1	
8	WER203K0288	WER203K0288	RACK	1	
9	WER203L1578	WER203L1578	CLICK SPRING	1	
10	WER203K3208	WER203K3208	SWITCH HANDLE	1	
11	WER203L3578	WER203L3578	SWITCH PLATE	1	
12	WER203L0308	WER203L0308	SHEET	1	
13	WER203K3288	WER204H3288	DIAL	1	
14	WER203L1008	WER203L1008	MOTOR BLOCK	1	
15	WER203L2508	WER203L2508	RECHARGEABLE BATTERY	1	
16	WER203L2108	WER204L2108	MODULE BLOCK	1	
17	WER203K7398	WER203K7398	COMB ATTACHMENT	1	
18	WER203K2058		AC CORD (STRAIGHT)	1	C2 PLUG
18		WER200B2069	AC CORD (CURL)	1	C2 PLUG
19	WER203X7918	WER203X7918	OIL	1	
20	WER210B7077	WER210B7077	CLEANING BRUSH	1	
21	WER203K7008	WER204K7008	SOFT CASE	1	
—	WER203K8008	WER204K8008	INDIVIDUAL BOX	1	OTHERS
—	WER203K8009	WER204K8009	INDIVIDUAL BOX	1	SCANDINAVIA
—	WER203K8108	WER203K8108	OPERATING INSTRUCTIONS	1	OTHERS
—	WER203K8109	WER203K8109	OPERATING INSTRUCTIONS	1	SCANDINAVIA