







Model No. : TX-P42C3E/J, CX3E, PR42C3 Exploded View 1



61 Assembly screw (4)	10 Assembly screw (4)	7 pole (1)	⚠ 8 Base (1)
			
M5 x 20	M5 x 25		







Model No. : TX-P42C3E/J, CX3E, PR42C3 Parts List

Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
	1	BAT-C-0487	Battery Cover of RC	1	PAVCCZ
	3	K2AHYH000042	AC INLET WITH CABLE	1	PAVCCZ
	4	K2CN3YY00006	AC CORD	1	P42C3E/CX3E, PR42C3
	4	K2CS3YY00010	AC CORD	1	PAVCCZ P42C3J
	5	MD42H14C1Z	PLASMA DISPLAY PANEL	1	PAVCCZ
	6	N2QAYB000487	REMOTE CONTROL	1	PAVCCZ
	7	TBL5ZA3028	STAND POLE	1	PAVCCZ
	8	TBL5ZX0030	PEDESTAL STAND	1	PAVCCZ
	9	TBX3EA00401	POWER BUTTON	1	
		THEJ036J	SCREW (P:5 TUNER SHEILD:3)	8	
		THEJ036J	SCREW (SN:6 SS:3 K-P:2)	11	
		THEJ036J	SCREW (DD:16 C:8)	24	
		THEJ0409	SCREW	8	PAVCCZ chap.3.1. (3)
		THEL052Z	SCREW	23	chap.3.1. (1)
	10	THEL088N	SCREW M5x25	4	PAVCCZ
	11	TKGA5669	FRONT GLASS	1	PAVCCZ
	12	TKK2AC5009	LED PANEL	1	PAVCCZ
	13	TKKL5493	M8 CAP	4	chap.3.1. (6)
	14	TMK0EG010	SPONGE (FRONT GLASS/LEFT/RIGHT)	2	PAVCCZ
	15	TMK0EG011	SPONGE (FRONT GLASS/UPPER/BOTTOM)	2	PAVCCZ
		TMME332	CLAMPER (HANGER:4 STAND BRACKET:2)	6	
		TMME332	CLAMPER	2	
		TMME332	CLAMPER (GLASS HOLDER BOTTOM)	3	
		TMME397	SPACER	3	PAVCCZ
	16	TMW3EX002	SP BRACKET L	2	
	17	TMW3EX003	SP BRACKET R	2	
	18	TMXX064	AC CORD CLAMPER A	1	
	19	TMXX065	AC CORD CLAMPER B	1	
	20	TMZ0E9925	STAND BRACKET	1	PAVCCZ
	21	TPC0EA04001	CARTON BOX	1	PAVCCZ
	22	TPD0E1151	TOP CUSHION	1	PAVCCZ
	23	TPD0E2157	BOTTOM CUSHION	1	PAVCCZ
	24	TPD0E9182	PEDESTAL CUSHION	1	PAVCCZ
	25	TPD0E9196	JOINT PAD	1	PAVCCZ
	26	TPDX0016-1	JOINT FOR PEDESTAL	1	
	27	TPE0E4047	SET BAG	1	PAVCCZ
	28	TPE0E9003	BAG FOR AC CORD	1	PAVCCZ
	29	TPE0E9008	BAG (INSTRUCTION BOOK)	1	PAVCCZ
	30	TPEB489	BAG (PEDESTAL STAND)	1	PAVCCZ
	31	TPEB512	BAG (STAND POLE)	1	PAVCCZ
		TPG0E4050	PAPER CAP	0.333 4	PAVCCZ
	32	TQB0E2066A	INSTRUCTION BOOK (GERMAN)	1	PAVCCZ P42C3E
	32	TQB0E2066B	INSTRUCTION BOOK (DUTCH)	1	PAVCCZ P42C3E
	32	TQB0E2066C	INSTRUCTION BOOK (ITALIAN)	1	PAVCCZ P42C3E
	32	TQB0E2066D	INSTRUCTION BOOK (FRENCH)	1	PAVCCZ P42C3E
	32	TQB0E2066E	INSTRUCTION BOOK (SPANISH)	1	PAVCCZ P42C3E
	32	TQB0E2066F	INSTRUCTION BOOK (SWEDISH)	1	PAVCCZ P42C3E
	32	TQB0E2066G	INSTRUCTION BOOK (NORWEGIAN)	1	PAVCCZ P42C3E
	32	TQB0E2066H	INSTRUCTION BOOK (FINNISH)	1	PAVCCZ P42C3E
	32	TQB0E2066I	INSTRUCTION BOOK (LITHUANIAN)	1	PAVCCZ P42C3E
	32	TQB0E2066J	INSTRUCTION BOOK (PORTUGUESE)	1	PAVCCZ P42C3E
	32	TQB0E2066K	INSTRUCTION BOOK (DANISH)	1	PAVCCZ P42C3E
	32	TQB0E2066M	INSTRUCTION BOOK (BULGARIAN)	1	PAVCCZ P42C3E
	32	TQB0E2066N	INSTRUCTION BOOK (ROMANIAN)	1	PAVCCZ P42C3E
	32	TQB0E2066O	INSTRUCTION BOOK (LATVIAN)	1	PAVCCZ P42C3E
	32	TQB0E2066P	INSTRUCTION BOOK (POLISH)	1	PAVCCZ P42C3E
	32	TQB0E2066Q	INSTRUCTION BOOK (HUNGARIAN)	1	PAVCCZ P42C3E
	32	TQB0E2066R	INSTRUCTION BOOK (CZECH)	1	PAVCCZ P42C3E
	32	TQB0E2066S	INSTRUCTION BOOK (GREEK)	1	PAVCCZ P42C3E
	32	TQB0E2066T	INSTRUCTION BOOK (TURKISH)	1	PAVCCZ P42C3E
	32	TQB0E2066U	INSTRUCTION BOOK (ENGLISH)	1	PAVCCZ P42C3E

Model No. : TX-P42C3E/J, CX3E, PR42C3 Parts List

Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
	32	TQB0E2066W	INSTRUCTION BOOK (SLOVAKIAN)	1	PAVCCZ P42C3E
	32	TQB0E2066V	INSTRUCTION BOOK (CROATIAN)	1	PAVCCZ P42C3E
	32	TQB0E2066Z	INSTRUCTION BOOK (ESTONIAN)	1	PAVCCZ P42C3E
	32	TQB0E2064A	INSTRUCTION BOOK (GERMAN)	1	PAVCCZ P42C3J
	32	TQB0E2064C	INSTRUCTION BOOK (ITALIAN)	1	PAVCCZ P42C3J
	32	TQB0E2064D	INSTRUCTION BOOK (FRENCH)	1	PAVCCZ P42C3J
	32	TQB0E20659	INSTRUCTION BOOK (KAZAKHSTAN)	1	PAVCCZ PR42C3
	32	TQB0E2065L	INSTRUCTION BOOK (RUSSIAN)	1	PAVCCZ PR42C3
	32	TQB0E2065Y	INSTRUCTION BOOK (UKRAINIAN)	1	PAVCCZ PR42C3
	32	TQB0E2129A	INSTRUCTION BOOK (GERMAN)	1	PAVCCZ P42CX3E
	32	TQB0E2129B	INSTRUCTION BOOK (DUTCH)	1	PAVCCZ P42CX3E
	32	TQB0E2129C	INSTRUCTION BOOK (ITALIAN)	1	PAVCCZ P42CX3E
	32	TQB0E2129D	INSTRUCTION BOOK (FRENCH)	1	PAVCCZ P42CX3E
	32	TQB0E2129E	INSTRUCTION BOOK (SPANISH)	1	PAVCCZ P42CX3E
	32	TQB0E2129F	INSTRUCTION BOOK (SWEDISH)	1	PAVCCZ P42CX3E
	32	TQB0E2129G	INSTRUCTION BOOK (NORWEGIAN)	1	PAVCCZ P42CX3E
	32	TQB0E2129H	INSTRUCTION BOOK (FINNISH)	1	PAVCCZ P42CX3E
	32	TQB0E2129I	INSTRUCTION BOOK (LITHUANIAN)	1	PAVCCZ P42CX3E
	32	TQB0E2129J	INSTRUCTION BOOK (PORTUGUESE)	1	PAVCCZ P42CX3E
	32	TQB0E2129K	INSTRUCTION BOOK (DANISH)	1	PAVCCZ P42CX3E
	32	TQB0E2129M	INSTRUCTION BOOK (BULGARIAN)	1	PAVCCZ P42CX3E
	32	TQB0E2129N	INSTRUCTION BOOK (ROMANIAN)	1	PAVCCZ P42CX3E
	32	TQB0E2129O	INSTRUCTION BOOK (LATVIAN)	1	PAVCCZ P42CX3E
	32	TQB0E2129P	INSTRUCTION BOOK (POLISH)	1	PAVCCZ P42CX3E
	32	TQB0E2129Q	INSTRUCTION BOOK (HUNGARIAN)	1	PAVCCZ P42CX3E
	32	TQB0E2129R	INSTRUCTION BOOK (CZECH)	1	PAVCCZ P42CX3E
	32	TQB0E2129S	INSTRUCTION BOOK (GREEK)	1	PAVCCZ P42CX3E
	32	TQB0E2129T	INSTRUCTION BOOK (TURKISH)	1	PAVCCZ P42CX3E
	32	TQB0E2129U	INSTRUCTION BOOK (ENGLISH)	1	PAVCCZ P42CX3E
	32	TQB0E2129W	INSTRUCTION BOOK (SLOVAKIAN)	1	PAVCCZ P42CX3E
	32	TQB0E2129V	INSTRUCTION BOOK (CROATIAN)	1	PAVCCZ P42CX3E
	32	TQB0E2129Z	INSTRUCTION BOOK (ESTONIAN)	1	PAVCCZ P42CX3E
	33	TQB0E2066X	INSTRUCTION BOOK (CD-ROM)	1	PAVCCZ P42C3E
	33	TQB0E2129X	INSTRUCTION BOOK (CD-ROM)	1	PAVCCZ P42CX3E
		TQZJ346	SCREW USE HANDBILE	1	PAVCCZ
	41	TSXM217	CABLE (C10-C20)	1	
	42	TSXM228	CABLE (C23-SS23)	1	PAVCCZ
	43	TSXM242	CABLE (A23-SN20)	1	PAVCCZ
	44	TSXM243	CABLE (A33-C11)	1	PAVCCZ
	45	TSXM244-1	CABLE (A34-C21)	1	PAVCCZ
	51	TTU0E0854	REAR COVER	1	PAVCCZ P42C3E
	51	TTU0E0856	REAR COVER	1	PAVCCZ P42C3J
	51	TTU0E0857	REAR COVER	1	PAVCCZ P42CX3E
	51	TTU0E0858	REAR COVER	1	PAVCCZ PR42C3
	52	TUX0EA023	42HANGER METAL	2	PAVCCZ
	53	TXFEA01RLUE	SPEAKER L/R ASSY	2	PAVCCZ
	54	TXFKP01RLUE	SIDE TERMINAL COVER ASSY	1	PAVCCZ
	55	TXFKY01RLUE	CABINET ASSY	1	PAVCCZ
		TXJA11RLUE	SPEAKER LEAD (A11-SPL/SPR)	1	PAVCCZ
		XTB4+12GFJ	SCREW (GH:14)	14	
		XTB4+12GFJK	SCREW (BC:11)	8	chap.3.1. (1)
		XTS4+10GFN	SCREW 4x10	12	
		XTV3+10JFJK	SCREW (REAR AV:2)	2	chap.3.1. (4)
		XYN3+F10FJK	SCREW	2	chap.3.1. (5)
		XYN3+F8FJ	SCREW (A-PRINT:4)	4	
		XYN3+J10FJ	SCREW	6	
		XYN4+E6FJ	SCREW (INLET:1)	1	
	61	XYN5+F20FN	SCREW M5x20 SILVER	4	PAVCCZ
		XZB6X12B03	POLY BAG (SCREW)	1	