



4.3 Exploded view


Top view



Bottom view



PARTS LISTS
Exploded View Set



	Cabinet parts	Gehäuseteile	Pieces de presentation
1	4822 464 51077	Frame	Rahmen
5	4822 443 51264	Bottom	Boden
9	4822 502 13173	Screw	Schraube
11	4822 502 21545	Screw	Schraube
12	4822 502 13884	Screw	Schraube
18	4822 443 64463	Cover	Abdeckung Matchline
18	4822 443 64463	Cover	Abdeckung
20	4822 443 41575	Control panel VR652/02	Bedienpaneel VR652/02
20	4822 443 41566	Control panel VR657/01/02	Bedienpaneel VR657/01/02
20	4822 443 41566	Control panel VR657/05	Bedienpaneel VR657/05
20	4822 443 41567	Control panel VR657/13/16	Bedienpaneel VR657/13/16
20	4822 443 41536	Control panel VR657/39	Bedienpaneel VR657/39
20	4822 443 41568	Contr. pan. VR757/01/02/13/16	Panneau de commande VR657/13/16
20	4822 443 64487	Control panel VR757/05	Bedienpaneel VR757/05
20	4822 443 41534	Control panel VR757/39	Panneau de com. VR757/01/02/13/16
28	4822 462 20815	Rear inlay	Panneau de commande VR757/05
30	4822 443 64464	Cover Matchline	hinterer Abdeckung
30	4822 443 64464	Cover	Deckel Matchline
31	4822 502 13173	Screw	Schraube
35	4822 462 42166	Foot	Fuß
36	4822 462 42166	Foot inlay	Fußeinlage
37	4822 502 21349	Screw	Schraube
150/1Δ	4822 321 10986	Mains cord	Netzkaabel
150/1Δ	4822 321 11041	Mains cord (only for UK)	Netzkaabel (nur für UK)
150/2	4822 321 23415	Antenna cable	Annenkabel
150/3	4822 321 63006	Scart cable (Easy Link)	Scartkabel (Easy Link)

	Onderdelen apparaat	Componentes muebla	Parti del mobile
1	4822 464 51077	Frame	Carcassa
5	4822 443 51264	Bottom	Fondo
9	4822 502 13173	Schroef	Vite
11	4822 502 21545	Schroef	Vite
12	4822 502 13884	Schroef	Vite
18	4822 443 64463	Deksel	Coperchio
18	4822 443 64463	Deksel	Coperchio Matchline
20	4822 443 41575	Bedienpaneel VR652/02	Panel de mandos VR652/02
20	4822 443 41569	Bedienpaneel VR657/01/02	Pannello di comandi VR657/01/02
20	4822 443 41567	Bedienpaneel VR657/05	Pannello di comandi VR657/05
20	4822 443 41536	Bedienpaneel VR657/13/16	Pannello di comandi VR657/13/16
20	4822 443 41568	Bedienpaneel VR657/39	Pannello di comandi VR657/39
20	4822 443 41568	Bedienpaneel VR757/05	Pannello di comandi VR657/13/16
20	4822 443 41534	Bedienpaneel VR757/39	Pannello di comandi VR757/05
28	4822 443 41534	Bedienpaneel VR757/39	Pannello di comandi VR757/39
30	4822 443 64464	Deksel	Rear inlay
30	4822 443 64464	Deksel	Coperchio Matchline
31	4822 502 13173	Schroef	Vite
36	4822 462 42166	Voet	Piede
37	4822 502 21349	Schroef	Suplementos de goma
150/1Δ	4822 321 10986	Netkabel	Cable de red
150/1Δ	4822 321 11041	Netkabel (alleen voor UK)	Cable de rete (solo para UK)
150/2	4822 321 23415	Antennekabel	Cable de antena
150/3	4822 321 63006	Scartkabel (Easy Link)	Cable de scart (Easy Link)