



1. Main

Exploded View




2. Assy Frame&Cover Parts

Exploded View



3. Assy Tub&Drum

Exploded View




This exploded view diagram illustrates the assembly of a washing machine door. The components are labeled with numbers:

- 0**: The main washing machine body.
- 1**: The door frame assembly, including the inner ring (1-1), outer ring (1-2), and the door panel (1-3).
- 2**: The door handle.
- 3**: The door lock assembly, including the lock body (3-1), lock cylinder (3-2), and lock cover (3-3).
- 3-4**: The door hinge pin.
- 3-5**: The door latch assembly, including the latch body (3-5-1) and latch bolt (3-5-2).
- 3-6**: The door seal assembly, including the seal ring (3-6-1), seal lip (3-6-2), and seal gasket (3-6-2-1, 3-6-2-2, 3-6-2-3, 3-6-2-4).
- 3-7**: The door hinge bracket.
- 3-8**: The door hinge pin.












5. Assy Panel Control

Exploded View



7. Small Parts

Exploded View

					
1	2	3	4	5	6
					
7	8	9	10	11	