





PACKING AND ACCESSORIES


To have your order filled promptly and correctly, please furnish the following information.

HOW TO ORDER REPLACEMENT PARTS

REF. NO.	PART NO.	DESCRIPTION	QTY	CODE
7-18	XWSSD40-10000	Washer: 4mm x 1mm	1	AA
7-19	XFTSD40P12000	Screw: 4mm x 12mm	1	AA
7-20	LX-BZA15OWREZ	Special screw	1	AB
7-21	KCPHWW40P08000	Screw: 4mm x 8mm	2	AB
7-22	KCPSD30P10000	Screw: 3mm x 10mm	2	AA
7-23	KBPSD30P28KS0	Screw: 3mm x 28mm	2	AA
7-24	XNESD30-24000	Nut: 3mm x 2.4mm	2	AA
7-25	KCPWW30P08000	Screw: 3mm x 8mm	2	AA
7-26	LX-BZA13WRZZ	Special screw	4	AB
7-27	XOTSD40P08000	Screw: 4mm x 8mm	4	AA

OVEN AND CABINET PARTS





Actual wire harness may be different from illustration.