

SHARP PARTS LIST

MICROWAVE OVEN WITH GRILL AND CONVECTION

MODEL R-93ST-A

HOW TO ORDER REPLACEMENT PARTS
To have your order filled promptly and correctly, please furnish the following information.

1. MODEL NUMBER
2. REF. NO.
3. PART NO.
4. DESCRIPTION

Parts marked "*" may cause undue microwave exposure.
Parts marked "⚠" are used in voltage more than 250V.


CONTENTS

[1] OVEN PARTS

[2] DOOR AND CONTROL PANEL PARTS

■ INDEX

PACKING AND ACCESSORIES






NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
[1] OVEN PARTS					
ELECTRIC PARTS					
△	C	RC-QZA219WRE1	AS		High voltage capacitor
	CH	RHET-A269WRZ1	AY		Convection heating element
	CM	RMOTE A415WRZ1	BB		Convection motor
	DM	RMOTDA269WRZ1	AP		Damper motor
	F1	QFS-BA012WRZZ	AG		Fuse 20A
	FM	RMOTE A002URE2	AV		Fan motor
	GH	RHET-A231WRZ1	AU		Grill heating element
△	MG	RV-MZA264WRE1	BG		Magnetron
	OL	RLMPTA066WRE1	AP		Oven lamp
	SW1	QSW-MA146WRZ1	AM		Monitored latch switch
	SW2	QSW-MA147WRZ1	AM		Stop switch
	SW3	QSW-MA146WRZ1	AM		Monitor switch
	SW4	QSW-MA147WRZ1	AM		Damper switch
△	T	RTRN-A016URE2	BL		High voltage transformer
	TC1	RTHM-A098WRE0	AK		Thermal cut-out 125°C (MG)
	TC2	RTHM-A109WRE0	AM		Thermal cut-out 170°C (GRILL)
	TC3	RTHM-A109WRE0	AM		Thermal cut-out 170°C (CONV.)
	TTM	RMOTDA267WRZ1	AP		Turntable motor
△	1-1	FH-DZA035WRE1	AS		High voltage rectifier assembly
	1-2	QACCV A004URE3	AT		Power supply cord
	1-3	FPWBFA309WRE4	AT		Noise filter (F2: Fuse F8A)
	1-4	RTRN-A529WRE1	AW		TC transformer
	1-5	FH-HZA075WRE0	AS		Thermistor
CABINET PARTS					
	2-1	GCABDA005URP1	BC		Back plate
	2-2	GCABUB053WRPZ	BR		Outer case cabinet
	2-3	GLEGPA057WRE2	AF		Foot
	2-4	GDAI-A003URP3	BA		Base plate
OVEN PARTS					
	4-1	PCUSUA312WRP0	AC		Cushion
	4-2	PCUSUA050URE0	AB		Cushion
	4-3	LANGFA002URP0	AL		Cavity support angle
	4-4	DOVN-A024URK0	BU		Oven cavity
	4-5	MCAMPA001URF1	AF		Damper cam
	4-6	LANGTA009URP2	AG		Damper angle
	4-7	FFTA-A001URK0	AM		Damper assembly
	4-9	PDUC-A011URF1	AQ		Air intake duct
	4-10	PDUC-A014URP0	AH		Exhaust duct
	4-11	PSKR-A010URP0	AF		Partition plate B
	4-12	PDUC-A012URP0	AL		Air duct
	4-13	LANGQA017URP0	AF		Grill heater angle
	4-14	QTANNA001URP0	AC		Earth plate
	4-15	PREFHA001URP0	AS		Grill reflector
	4-16	LANG-A054WRP1	AK		Convection heater angle
	4-17	LANGQA308WRP1	AK		Convection motor angle
	4-18	NFANMA003URP0	AF		Cooling fan
	4-19	PDUC-A042URP0	AG		Convection duct
	4-20	PIPF A005UR10	AK		Pipe
	4-21	PSKR-A013URP0	AG		Air separate angle A
	4-22	PSKR-A014URP0	AF		Air separate angle B
	4-23	PSKR-A015URP0	AF		Air separate angle C
	4-24	PSKR-A016URP0	AF		Air separate angle D
	4-25	PSLDHA005URP0	AQ		Rear heat cover
	4-26	LANGQA018URP1	AM		Convection heater angle A
	4-27	PFPF-A002URE1	AL		Heat insulating material
	4-28	PSKR-A012URP0	AG		Air separate angle E
	4-29	PSKR-A308WRF1	AL		Rear barrier
	4-30	NFANMA004URP0	AG		Convection fan
	4-31	PHOK-A002URF1	AT		Latch hook
	4-32	PDUC-A016URF1	AQ		Fan duct
	4-33	NFANJA038WRE0	AG		Fan blade
	4-34	GCOVHA002URP0	AG		Bottom heater cover
	4-35	LANGFA001URP1	AL		Chassis support
	4-36	NCPL-A040WRE2	AL		Coupling
	4-37	PCOVPA309WRE0	AF		Waveguide cover
	4-38	PFPF-A003URE2	AM		Heat insulating material
	4-39	PFLWA001URP0	AG		Lamp filter
	4-40	PPACGA101WRE0	AF		O-ring
	4-41	PSLDHA002URP3	AS		Heater cover right
	4-42	PSPAGA001WRE0	AB		Vibration proof cushion
	4-43	LBNDKA111WRP1	AG		Capacitor holder
MISCELLANEOUS					
	6-1	FROLPA060WRK0	AW		Roller stay
	6-2	NTNT-A040WRE0	AZ		Turntable tray
	6-10	LHLDKA008WRF1	AF		P-clip
	6-11	TCAUHA024URR0	AE		Caution label
SCREWS, NUTS AND WASHERS					
	7-1	XHPS740P08K00	AB		Screw: 4mm x 8mm
	7-2	LX-EZA042WRE0	AB		Special screw
	7-3	XCBBWW30P06000	AA		Screw: 3mm x 6mm
	7-4	XNEUW40-32000	AA		Nut: 4mm x 3.2mm
	7-5	XRES740-06000	AB		Ring

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
[1] OVEN PARTS					
7-6	XWSUW40-10000	AA			Washer: 4mm x 1.0mm
7-7	XEPS740P25000	AB			Screw: 4mm x 25mm
7-8	XHPS730P06000	AB			Screw : 3mm x 6mm
7-9	XJPS740P10X00	AB			Screw: 4mm x 10mm
7-10	XHPS740P06000	AB			Screw: 4mm x 6mm
7-11	XOTWW40P10000	AA			Screw : 4mm x 10mm
7-12	XPWW30P05K00	AA			Screw: 3mm x 5mm
7-13	XHTWW40P08000	AC			Screw: 4mm x 8mm
7-14	XJBS730P16000	AC			Screw: 3mm x 16mm
7-15	XHTS740P08RV0	AG			Screw: 4mm x 8mm
7-16	LX-CZA001URE0	AC			Special screw
7-17	XOTS740P10000	AB			Screw: 4mm x 10mm

[2] DOOR AND CONTROL PANEL PARTS



NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
[2] DOOR AND CONTROL PANEL PARTS					
CONTROL PANEL PARTS					
3-1	DPWBFA197URK0	BT			Control unit
3-2	FPWBFA064URK0	AY			Switch unit
3-3	HPNLCR205URF0	AS			Control panel
3-4	GMAD i S205URR0	AP			Display window
3-5	JBTN-S225URT0	AK			More less button
3-6	JBTN-S230URT0	AK			Auto cook button
3-7	JBTN-S235URT0	AM			Stop watt button
3-8	JKNBKS210URT0	AK			Select knob
3-9	JKNBKS008URT0	AK			Timer knob
3-10	HDECQA315WRRZ	AX			Panel decoration
3-11	MSPR-A006WREZ	AF			Switch spring
3-12	XEPS730P10X00	AA			Screw : 3mm x 10mm
DOOR PARTS					
5-1	CDORFS027URK0	BS			Door panel assembly
5-1-1	GCOVHA024URF0	AT			Choke cover
5-1-2	DDORFA001URK0	BG			Door panel
5-1-3	GWAKPR205URF0	AU			Door frame
5-1-4	JHNDPS200URT0	AW			Door handle
5-1-5	LSTPPA017URF0	AK			Latch head
5-1-6	MSPRTA197WREZ	AF			Latch spring
5-1-7	PGLSPA029URE0	AY			Front door glass
5-1-8	XEBS730P06000	AC			Screw : 3mm x 6mm
5-1-9	LSTPPA021URF0	AH			Glass stopper
5-1-10	HDECQS200URR0	BD			Door decoration
5-1-11	XCTS740P20000	AC			Screw : 4mm x 20mm
5-1-12	PCUSUA033URE0	AF			Cushion
5-2	LSTPPA018URF0	BB			Door stopper
MISCELLANEOUS					
6-3	PSRA-A025WRP1	AY			Baking tray
6-4	FAM i -A001URK1	AT			High rack
6-5	FAM i -A002URK1	AT			Low rack
6-6	TLABMB127WRRZ	AL			Menu label
6-7	TCADCA896WRRZ	AP			Operation manual with Cook book
6-8	FW-VZA104URE2	BD			Main harness
6-9	FW-VZA074URE4	AN			Stop switch harness
6-12	T i NS-A703WRRZ	AM			Quick start guide

■INDEX

PARTS CODE	No.	PRICE RANK	NEW MARK	PART RANK
【 C 】				
CDORFS027URK0	2-5-1	BS		
【 D 】				
DDORFA001URK0	2-5-1-2	BG		
DOVN-A024URK0	1-4-4	BU		
DPWBFA197URK0	2-3-1	BT		
【 F 】				
FAMI-A001URK1	2-6-4	AT		
FAMI-A002URK1	2-6-5	AT		
FFTA-A001URK0	1-4-7	AM		
FH-DZA035WRE1	1-1-1	AS		
FH-HZA075WRE0	1-1-5	AS		
FPWBFA064URK0	2-3-2	AY		
FPWBFA309WRE4	1-1-3	AT		
FROLPA060WRK0	1-6-1	AW		
FW-VZA074URE4	2-6-9	AN		
FW-VZA104URE2	2-6-8	BD		
【 G 】				
GCABDA005URP1	1-2-1	BC		
GCABUB053WRPZ	1-2-2	BR		
GC0VHA002URP0	1-4-34	AG		
GC0VHA024URF0	2-5-1-1	AT		
GDAI-A003URP3	1-2-4	BA		
GLEGPA057WRE2	1-2-3	AF		
GMADIS205URR0	2-3-4	AP		
GWAKPR205URF0	2-5-1-3	AU		
【 H 】				
HDECQA315WRRZ	2-3-10	AX		
HDECQS200URR0	2-5-1-10	BD		
HPNLCR205URF0	2-3-3	AS		
【 J 】				
JBTN-S225URT0	2-3-5	AK		
JBTN-S230URT0	2-3-6	AK		
JBTN-S235URT0	2-3-7	AM		
JHNDPS200URT0	2-5-1-4	AW		
JKNBKS008URT0	2-3-9	AK		
JKNBKS210URT0	2-3-8	AK		
【 L 】				
LANG-A054WRP1	1-4-16	AK		
LANGFA001URP1	1-4-35	AL		
LANGFA002URP0	1-4-3	AL		
LANGQA017URP0	1-4-13	AF		
LANGQA018URP1	1-4-26	AM		
LANGQA308WRP1	1-4-17	AK		
LANGTA009URP2	1-4-6	AG		
LBNDKA111WRP1	1-4-43	AG		
LHLDKA008WRF1	1-6-10	AF		
LSTPPA017URF0	2-5-1-5	AK		
LSTPPA018URF0	2-5-2	BB		
LSTPPA021URF0	2-5-1-9	AH		
LX-CZA001URE0	1-7-16	AC		
LX-EZA042WRE0	1-7-2	AB		
【 M 】				
MCAMPA001URF1	1-4-5	AF		
MSPR-A006WREZ	2-3-11	AF		
MSPRTA197WREZ	2-5-1-6	AF		
【 N 】				
NCPL-A040WRE2	1-4-36	AL		
NFANJA038WRE0	1-4-33	AG		
NFANMA003URP0	1-4-18	AF		
NFANMA004URP0	1-4-30	AG		
NTNT-A040WRE0	1-6-2	AZ		
【 P 】				
PCOVPA309WRE0	1-4-37	AF		
PCUSUA033URE0	2-5-1-12	AF		
PCUSUA050URE0	1-4-2	AB		
PCUSUA312WRP0	1-4-1	AC		
PDUC-A011URF1	1-4-9	AQ		
PDUC-A012URP0	1-4-12	AL		
PDUC-A014URP0	1-4-10	AH		
PDUC-A016URF1	1-4-32	AQ		
PDUC-A042URP0	1-4-19	AG		
PFI LWA001URP0	1-4-39	AG		
PFPF-A002URE1	1-4-27	AL		
PFPF-A003URE2	1-4-38	AM		
PGLSPA029URE0	2-5-1-7	AY		
PHOK-A002URF1	1-4-31	AT		
PPACGA101WRE0	1-4-40	AF		
PPiPFA005UR10	1-4-20	AK		

PARTS CODE	No.	PRICE RANK	NEW MARK	PART RANK
PREFHA001URP0	1-4-15	AS		
PSKR-A010URP0	1-4-11	AF		
PSKR-A012URP0	1-4-28	AG		
PSKR-A013URP0	1-4-21	AG		
PSKR-A014URP0	1-4-22	AF		
PSKR-A015URP0	1-4-23	AF		
PSKR-A016URP0	1-4-24	AF		
PSKR-A308WRF1	1-4-29	AL		
PSLDHA002URP3	1-4-41	AS		
PSLDHA005URP0	1-4-25	AQ		
PSPAGA001WRE0	1-4-42	AB		
PSRA-A025WRP1	2-6-3	AY		
【 Q 】				
QACCVAA004URE3	1-1-2	AT		
QFS-BA012WRZZ	1-F1	AG		
QSW-MA146WRZ1	1-SW1	AM		
"	1-SW3	AM		
QSW-MA147WRZ1	1-SW2	AM		
"	1-SW4	AM		
QTANNA001URP0	1-4-14	AC		
【 R 】				
RC-QZA219WRE1	1-C	AS		
RHET-A231WRZ1	1-GH	AU		
RHET-A269WRZ1	1-CH	AY		
RLMPTA066WRE1	1-OL	AP		
RMOTDA267WRZ1	1-TTM	AP		
RMOTDA269WRZ1	1-DM	AP		
RMOTEA002URE2	1-FM	AV		
RMOTEA415WRZ1	1-CM	BB		
RTHM-A098WRE0	1-TC1	AK		
RTHM-A109WRE0	1-TC2	AM		
"	1-TC3	AM		
RTRN-A016URE2	1-T	BL		
RTRN-A529WRE1	1-1-4	AW		
RV-MZA264WRE1	1-MG	BG		
【 T 】				
TCADCA896WRRZ	2-6-7	AP		
TCAUHA024URR0	1-6-11	AE		
TINS-A703WRRZ	2-6-12	AM		
TLABMB127WRRZ	2-6-6	AL		
【 X 】				
XPWW30P05K00	1-7-12	AA		
XCBWW30P06000	1-7-3	AA		
XCTS740P20000	2-5-1-11	AC		
XEBS730P06000	2-5-1-8	AC		
XEPS730P10X00	2-3-12	AA		
XEPS740P25000	1-7-7	AB		
XHPS730P06000	1-7-8	AB		
XHPS740P06000	1-7-10	AB		
XHPS740P08K00	1-7-1	AB		
XHTS740P08RV0	1-7-15	AG		
XHTWW40P08000	1-7-13	AC		
XJBS730P16000	1-7-14	AC		
XJPS740P10X00	1-7-9	AB		
XNEUW40-32000	1-7-4	AA		
XOTS740P10000	1-7-17	AB		
XOTWW40P10000	1-7-11	AA		
XRES740-06000	1-7-5	AB		
XWSUW40-10000	1-7-6	AA		