



Gebrauchsanweisung
 52 3437
 (D,GB,NL,F,I,RS)

Kochbuch
 52 3438
 (D)

Aufkleber
 52 3436
 (D,GB,NL,F,I,RS,S,DK,
 E)

Zubehör:

Einbaurahmen
 HZ 66021
 V01
 HZ 66041
 V02
 HZ 66061
 V03

1) 03 2620
 2) 16 0651





