




Gebrauchsanweisung


58 3129
(de,en,fr,nl)
58 3130
(it,el,es,pt)
58 6879
(de)
58 8139
(en)
58 8557
(fr)
58 8558
(nl)
58 8559
(it)
58 8561
(es)

Kurzanleitung

58 3100
(de,en,fr,nl)
58 3101
(it,el,es,pt)
58 6878
(de)
58 7325
(en)
58 7738
(fr)
58 7814
(nl)
58 8562
(it)
58 8563
(es)

Montage- / Aufstell- anleitung

52 8864
V01-V04
58 4527
V05



Zubehör:

Entkalker
46 0038

Verlg. Aqua-Stop
Kunststoffrohr 2,2 m
Ablaufschl. 1,95 m
SZ72010

Kupferrohr
Ø 10 mm / 1,5 m
WX459700

Messerkas.-Backbl.-
Düse
SZ72000

Silberglanzkassette
SZ78100

Spülhilfe Set
SZ72030

Korbeinsatz für
Langstielgläser
SZ70640



