


4-2-4. BEZEL ASSY



REF. No.	PART No.	DESCRIPTIONRE	MARK
351	X-2023-470-1	BEZEL ASSY (Black)	352-354
	X-2024-231-1	BEZEL ASSY (Silver)	
352	2-021-791-13	BUTTON, POWER (Black)	
	2-021-791-03	BUTTON, POWER (Silver)	
353	2-109-058-01	SPRING, COMPRESSION	
354	2-050-241-01	GUIDE, LED	
355	* A-1052-778-A	H2 MOUNT	

REF. No.	PART No.	DESCRIPTIONRE	MARK
356	4-302-404-03	SCREW (WASHER HEAD) (+P 4X16)	
357	* A-1052-780-A	H1 MOUNT	
358	* A-1052-781-A	H3 MOUNT	
359	X-2021-445-3	FRONT TERMINAL ASSY (Black)	
	X-2021-727-3	FRONT TERMINAL ASSY (Silver)	
360	1-826-043-11	LOUDSPEAKER (5X15CM)	
#8	7-685-648-79	SCREW +BVTP 3X12, TYPE 2, IT-3	