


8-5. SCREEN AND COVER BLOCK (KP-61)

■ : 7-685-661-79 +BVTP 4X12
○ : 7-685-663-79 +BVTP 4X16



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
201	X-4037-601-1	BEZNET (61) ASSY		212	4-075-234-11	HOLDER, MIRROR	
202	4-378-522-31	SCREW, TAPPING, HEXAGON HEAD		213	* 4-069-689-01	HOLDER (L), MIRROR	
203	4-065-813-11	SCREEN (61AR), CONTRAST		214	4-070-922-01	MIRROR, REFLECTION	
204	4-070-283-11	PLATE (L), DIFFUSION		215	* X-4037-602-1	COVER (61) ASSY, MIRROR	
205	4-066-082-11	PLATE (F), DIFFUSION		216	* 4-069-690-01	HOLDER (R), MIRROR	
206	* 4-205-155-01	COVER, SENSOR		217	* 4-075-248-01	BOARD (61), REAR	
207	1-528-864-11	BATTERY, SOLAR		218	X-4037-600-1	GRILLE ASSY, SPEAKER	
208	* 4-066-132-01	HOLDER, SENSOR		219	1-529-759-11	SPEAKER (16 CM)	
209	4-072-006-01	HOLDER (V61), SCREEN		220	1-529-758-11	SPEAKER (8 CM)	
210	4-072-005-01	HOLDER (H61), SCREEN		221	1-529-757-11	SPEAKER (2.7 CM)	