


KP-48PS1/53PS1/61PS1
48PS1K/53PS1K/61PS1K
 RM-892

8-6. CONTROL PANEL AND CABINET BLOCK (KP-61)

- ▲ : 7-685-534-19 +BTP 2.6X8
 △ : 7-685-648-79 +BVTP 3X12
 ● : 7-685-663-71 +BVTP 4X16

The components identified by shading and mark ▲ are critical for safety.
 Replace only with part number specified.



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
251	X-4037-626-1	TRAY (L) ASSY		252	265	4-072-000-11 TRAY (R)	
252	4-072-001-02	TRAY (L)		266	* A-1372-758-A	H2 BOARD, COMPLETE	
253	4-071-999-12	PANEL (T)		267	* A-1372-759-A	H3 BOARD, COMPLETE	
254	4-072-007-11	PANEL (C)		268	4-072-013-11	SKIRT (61), FRONT	
255	X-4037-024-2	PANEL ASSY, CONTROL	256, 257	269	4-378-522-31	SCREW, TAPPING, HEXAGON HEAD	
256	4-071-997-01	BUTTON, MULTI		270	* X-4037-599-2	CABINET (61) ASSY	269, 271-273
257	4-919-393-01	DAMPER		271	4-063-421-02	LATCH (K)	
258	4-071-995-01	BUTTON, POWER		272	4-075-874-01	FOOT, PLASTIC	
259	* A-1372-757-A	H1 BOARD, COMPLETE		273	4-030-850-01	SOCKET, CASTER	
260	* 4-071-998-01	BRACKET (HA)		274	4-039-546-01	CASTER	
261	X-4037-221-2	HOLDER ASSY, TRAY		275	▲ 1-223-925-11	RESISTOR ASSY (HIGH-VOLTAGE)	
262	4-047-464-01	CATCHER, PUSH	262			(FOCUS PACK)	
263	4-075-242-01	SPRING (T)		276	* 4-054-825-01	BRACKET, FOCUS PACK	
264	X-4037-625-1	TRAY (R) ASSY	265				