All screws are Phillips (cross recess) type unless otherwise noted. (-) = slotted head • Circled letters (A to 2) are applicable to 4-847-090-00 ® Lever (2), brake European models only. 4-847-562-00 (A) Spring E 3 9-911-815-02 © Cushion (t = 5) Lever (1) Ass'y, brake-4-847-018-00 **(A)** Spring 3-701-441-21 (§) Washer, plastic; 4 mm dia. X-4857-015-0 \bigcirc Lever (A) Ass'y, lead-in; including parts marked \bigcirc A-C P 3 x 16 ■ C 4-852-804-00 (A) Cam, adjustment 4-852-846-00 A ■ 8 4-853-088-00 (A) Roller l.ever Ass'y, record size selector (E) 4-847-024-00 ® Cam, return E 2 4-853-087-00 (8) Cushion 3-486-138-00 (A) Slide Pin 3-701-437-11 (Å) Washer, plastic; 2 m 4-852-844-00 B 4 4-852-843-00 **(A)** Tube, cushion 4-847-017-00 (A) Spring .4-847-035-00 (A) Tube, cushion Lever, reset 3-701-441-21 (A) Washer, plastic; 4 mm dia **3** am Ass'y, record size selector 4-847-544-00 🚯 PTT 3x 14 PTP 3×8 PTT 3×8 Sub Frame Ass'y

Main Lever Ass'y

1-552-103-00 © Switch, minieture; timing (S1)

4-847-044-00 **(**) Roller