

- -XX, -X mean standardized parts, so they may have some differences from the original one.
- Color Indication of Appearance Parts
Example:
KNOB, BALANCE (WHITE) ... (RED)

- The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

This exploded view diagram illustrates the assembly of a washing machine, showing the relationship between various components and their assembly order. The components are numbered 1 through 42, with some parts having alternative configurations for different models.

Key Components and Assembly Notes:

- 13:** Top panel.
- 12:** Front panel.
- 11:** Door panel.
- 16:** Door hinge.
- 14:** Door latch.
- 18:** Mounting brackets for the door.
- 19:** Door seal.
- 20:** PT901 component.
- 21:** Mounting bracket for the PT901.
- 22:** Mounting bracket for the PT901.
- 23:** Mounting bracket for the PT901.
- 24:** D705P only component.
- 26:** (Including 28) component.
- 27:** Component.
- 28:** Component.
- 29:** Component.
- 30:** Component.
- 31:** Component.
- 32:** Component.
- 33:** Component.
- 34:** Component.
- 35:** Component.
- 36:** Component.
- 37:** Component.
- 38:** Component.
- 39:** not supplied component.
- 40:** D705P only component.
- 41:** Component.
- 42:** Component.

Model-Specific Notes:

- D705: AEP, G, IT model:** PT901 component.
- D705: E, EA model:** D705P only component.
- D705: E model:** D705P only component.
- D705 model:** SW3 component.
- D705 model:** SW2 component.

Ref. No.	Part No.	Description	Remark
23	4-944-675-01	ARM, ELEVATION	
24	1-551-294-00	CORD (PHONO)	
26	A-4604-840-A	ARM ASSY, TONE	
27	* 4-944-672-01	BUSHING, TONE ARM	
28	4-944-756-01	CARTRIDGE	
29	4-944-704-01	ARM (B), FEED	
30	4-944-705-01	SPRING, FEED ARM	
31	4-944-759-01	ADJUSTMENT, CAM LEAD IN	
32	4-944-760-01	ADJUSTMENT, CAM LEAD AUTORETURN	
33	* 1-639-237-11	PC BOARD, PHONO	
34	4-944-674-01	LEVER, CUIING	
35	* 4-944-685-01	BRACKET, CUIING	
36	4-944-695-01	SCREW	
37	4-944-673-01	LOCKER, ARM	
38	4-944-687-01	SPRING, ELEVATION	
39	* A-4604-842-A	MECHANICAL ASSY, BASE	
40	1-590-871-11	CORD (WITH CONNECTOR) 3P (D705P)	
41	4-944-703-01	ARM (A), FEED	
42	4-944-688-01	LINK, START CUT	
CNP1	△ 1-555-750-00	CORD, POWER (D705:AEP, G. IT, EA)	
CNP1	△ 1-551-188-XX	CORD, POWER (D705:E)	
PT901	△ 1-450-508-11	TRANSFORMER, POWER (D705)	
SW2	1-572-744-11	SWITCH, PUSH (SPEED)	
SW3	1-572-744-11	SWITCH, PUSH (POWER) (D705)	