



Libro de instrucciones  
51 7577  
(E)


1) 28 8341  
V01, V04  
28 8339  
V02, V05  
29 8843  
V03, V06





1) 14 1162  
V01,V02,V04,V05  
14 1161  
V03,V06

\* Conj. tornill. tambor  
05 9132



1) 28 7984