


SPAREPARTLIST

Pos	12NC	Description
001	4812 440 58337	Cover
002	4812 440 58336	Cover
003	4801 231 00044	Insert
004	4801 231 00026	Lock
005	4820 000 00696	Side panel left
006	4801 231 00451	Knob
007	4812 418 48935	Container
008	4820 000 00697	Panel rear
009	4820 000 00695	Side panel right
011	4820 000 02647	Tray
012	4820 000 00698	Door complete
013	4820 000 00706	Tube, clue
014	4812 440 58338	Cover
015	4812 418 38169	Container
016	4812 404 88115	Batten
017	4812 418 38171	Tray drip
018	4820 000 02648	Outflow-set
019	4812 404 49803	Support
020	4812 530 49336	Floater
021	4812 011 78407	Measuring container
022	4812 459 28079	Frame
023	4801 231 00434	Ventilator
024	4812 418 38173	Tray
025	4812 418 18681	Tray
026	4812 271 38527	Microswitch
027	4812 404 88125	Guide right
028	4812 404 88124	Guide left
029	4820 000 01892	Base
030	4820 000 00712	LED Board
031	4820 000 00711	Control board with LED display
032	4820 000 02649	Microswitch
033	4812 013 18003	Gear grinder cpl. until week 52/2012
034	4812 466 88972	Gasket
035	4812 479 58002	Nozzle diffuser
036	4812 466 88974	O-Ring
037	4820 000 00715	valve
038	4812 123 88004	Fuse thermo
039	4801 231 00441	thermal fuse
040	4812 404 49799	Support
041	4812 492 98053	Spring
042	4812 271 38526	Microswitch
043	4820 000 00611	Guide
044	4812 532 48064	Bushing
045	4812 532 48063	Bushing
046	4812 282 68058	Sensor
047	4801 231 00454	O-Ring
048	4812 226 08047	Pin
049	4812 360 58575	Valve
050	4812 492 98055	Spring
052	4812 480 88058	Filter

Pos	12NC	Description
053	4820 000 00718	Generator thermoblock
054	4812 214 70243	Platine
056	4812 282 68061	Feeler board
057	4812 358 18211	Belt
058	4820 000 00714	Gear transmission kit
059	4820 000 00710	Terminal block
060	4801 231 00455	O-Ring # 3.85
061	4820 000 01634	Holder
062	4820 000 01635	Valve
063	4820 000 00716	Thermofuse
064	4812 360 18581	Pump
065	4812 404 49805	Support
066	4820 000 00719	Sensor reed
067	4820 000 00713	Power unit
069	4801 231 00449	Pin
070	4820 000 01636	Nut
071	4820 000 01637	Bush
072	4820 000 00723	Connection
073	4801 231 00456	o-Ring
074	4812 259 28957	Heating element
075	4812 123 88006	Fuse overheat
076	4801 231 00067	Support rubber fan motor
078	4812 282 98015	Flowmeter
079	4820 000 00720	Tube reed
080	4801 231 00432	Gasket
081	4801 231 00448	connection
082	4820 000 01638	Tube L=150
083	4812 492 98051	Spring
084	4801 231 00445	Connection
085	4801 231 00457	o-Ring # 4.5
086	4812 580 38019	Filter
087	4812 458 28034	Tube
088	4801 231 00453	Spring
090	4801 231 00446	Connection
091	4812 360 58573	VENTIEL
092	4812 458 28035	Tube
093	4812 360 58572	KIT ELETTRIVAL(2pz) 230V+ Junction (3pz)
094	4820 000 02650	Frame+touch screen+supportPCB LED etc.
095	4820 000 00727	O-Ring
096	4820 000 00721	Coupling carafe
098	4820 000 00728	O-Ring
099	4820 000 00699	Cover door
100	4812 404 49737	Strap
101	4820 000 00724	Connection
102	4812 417 58401	Hook
103	4812 548 28059	Hose 170 mm long
104	4820 000 00726	Spring microswitch
105	4820 000 00725	Holder
106	4820 000 00700	Spring
107	4820 000 00703	Cover carafe


Pos	12NC	Description
108	4820 000 00702	Carafe
112	4820 000 00704	Pipette
113	4812 492 98052	Spring
114	4812 404 49798	Lever
115	4812 502 18781	Screw
116	4812 462 58099	Stopper
117	4812 360 58574	Valve
118	4801 231 00452	Spring
119	4801 231 00046	Piston
120	4812 404 49804	Support
121	4820 000 00709	Button ON/OFF
122	4820 000 00701	Front
123	4820 000 02651	Glass panel
126	4820 000 00705	Tube
127	4812 466 88949	O-ring
128	4801 231 00439	regulator

IMAGE EXPLODED VIEW




81003117

IMAGE EXPLODED VIEW




81003118

IMAGE EXPLODED VIEW



81003119

IMAGE EXPLODED VIEW



81003120