

Spare Part List

Pos	12NC	Description
025 2	4812 460 79231	Trim lower
040 0	4812 417 19339	Hinge
047 0	4812 417 19137	Hinge run.mech.
110 0	4812 498 68302	Door handle
110 1	4819 462 48443	Rubber
121 3	4812 460 58418	Exhaust fume Venturi
141 0	4812 450 59856	Oven glass assy+support
142 0	4812 450 59567	Inner glass
143 1	4812 404 49841	Support glass
191 0	4812 466 88874	Gasket door
201 0	4812 442 69486	Panel rear
245 0	4812 458 19334	Oven shelf
247 0	4812 418 38138	Fat pan
301 0	4812 452 40275	Panel control AMPERE
332 0	4812 410 78186	Button,push Ampere
334 0	4812 412 79421	Knob
350 0	4812 130 38793	Display Ampere
440 0	4812 361 18604	Motor fan
441 0	4812 361 18527	Ventilator cooling
443 0	4819 515 48065	Fan wheel
451 0	4812 259 98406	Heating element forced-air 230 V
452 0	4812 259 98518	Heating element upper/grill
456 0	4812 259 98517	Heating element lower 230V
490 1	4812 290 68255	Clamp cable
490 2	4812 316 18036	Cover cable
491 0	4812 290 68329	Connectionblock
521 0	4812 214 58345	Power unit Ampere
554 0	4812 282 08669	Thermostat
557 0	4812 282 28209	Temper.limiter
557 1	4812 282 28329	Temper.limiter 3-way
557 2	4812 282 28282	Temper.limiter
620 0	4812 273 18098	Switch,oven MF8
651 0	4819 134 88153	Lamp,oven
652 0	4819 255 18237	Holder lamp rear
656 0	4812 450 28007	Lamp screen rear
915 0	4819 505 18145	Nut
993 0	4812 310 39061	Spacer

