


## Spare Part List

Pos	12NC	Description
001 0	<b>4812 440 58333</b>	Cover
010 0	<b>4812 310 39125</b>	Mounting frame
022 0	<b>4812 440 58332</b>	Side panel
247 1	<b>4812 418 38154</b>	Tray leak
247 2	<b>4812 418 38156</b>	Tray leak
247 9	<b>4812 418 38155</b>	Tray leak drip tray
320 0	<b>4812 453 50268</b>	Panel control
331 0	<b>4812 410 78207</b>	Knob BL
332 0	<b>4812 410 78208</b>	Button
350 0	<b>4812 214 58409</b>	Unit control
351 0	<b>4812 134 88079</b>	Pilot lamp red
351 1	<b>4812 134 88081</b>	Pilot lamp white
430 0	<b>4812 360 18581</b>	Pump
430 9	<b>4812 404 49733</b>	Support
483 9	<b>4812 290 68345</b>	Connector
490 0	<b>4812 321 18296</b>	Cable mains SA
521 0	<b>4812 310 88428</b>	Boiler kit
521 1	<b>4801 231 00312</b>	Distributor boiler
521 2	<b>4801 231 00313</b>	Gasket boiler
562 0	<b>4812 282 48296</b>	Thermostat 125C
562 1	<b>4812 282 48295</b>	Thermostat 105C
571 7	<b>4812 502 18762</b>	Screw
572 0	<b>4812 282 28339</b>	Valve
572 1	<b>4812 281 38003</b>	Valve
620 9	<b>4812 271 38515</b>	Switch
621 0	<b>4812 271 38516</b>	Switch
700 0	<b>4801 231 00315</b>	Hose inlet steam valve 150 mm
700 0	<b>4801 231 00316</b>	NODHose inlet boiler 190 mm
702 0	<b>4812 548 28058</b>	Hose
702 1	<b>4812 548 28059</b>	Hose
702 2	<b>4812 458 28028</b>	Hose
702 3	<b>4812 458 28031</b>	Tube
702 5	<b>4812 530 88027</b>	Insert
726 0	<b>4812 458 28029</b>	Tube frother
726 1	<b>4812 548 28061</b>	Tube lower
726 5	<b>4812 440 08043</b>	Cover nozzle
741 1	<b>4812 404 49736</b>	Rod
741 2	<b>4812 404 49735</b>	Support
741 3	<b>4812 404 49734</b>	Support
750 0	<b>4812 418 89073</b>	Tank
750 8	<b>4812 440 58334</b>	Cover water tank
750 9	<b>4812 404 78836</b>	Decorplate
762 0	<b>4812 480 88031</b>	Filter
781 1	<b>4812 530 49217</b>	Floater
900 3	<b>4812 404 49737</b>	Strap
910 0	<b>4812 500 18112</b>	Screwed joint
910 1	<b>4812 404 49732</b>	Support hose
910 2	<b>4812 500 18113</b>	Fitting
930 0	<b>4801 231 00425</b>	Spring
930 1	<b>4812 492 98046</b>	Spring


<b>Pos</b>	<b>12NC</b>	<b>Description</b>
930 2	<b>4812 492 98047</b>	Spring
950 3	<b>4812 466 88945</b>	Gasket
950 4	<b>4812 466 88947</b>	O-Ring
950 5	<b>4812 466 88948</b>	O-Ring
950 6	<b>4812 466 88949</b>	O-Ring
950 7	<b>4812 466 88944</b>	Gasket O-ring
950 8	<b>4812 466 88946</b>	Ring
963 0	<b>4812 404 49715</b>	Angle iron installation
971 1	<b>4812 252 28062</b>	Fuse
993 0	<b>4812 498 98012</b>	Grip filter holder
993 1	<b>4812 404 49738</b>	Lever
993 2	<b>4812 480 88032</b>	Filter large
993 3	<b>4812 480 88033</b>	Filter small

### Exploded View



80000647

## Exploded View



80000654