





1-54 (No. 20393)




(3) Front Section

A B C D E F G H I J K L M N O P Q R S T




ENB-162	B	C	D	E	F	G	H	I	J	H
D931	O	O	-	-	-	-	O	-	-	-
D932	-	-	-	-	-	-	O	O	O	-
D933	O	O	O	-	-	-	O	O	O	-
D934	-	-	-	-	-	-	O	-	O	-

(4) Tuner Section (without LW)




* MARK	U	A	J.C
R109	68 UNF. F. (1/4W)	68 UNF. F. (1/4W)	68 UNF. C. (1/4W)
R157	39K	47K	39K
R160	5. 6K	10K	5. 6K
R151, 162	82K	100K	82K
R163, 164	4. 7K	3. 3K	4. 7K
R165, 166	180K	270K	180K
C177, 178	820P	560P	820P
R158	27K	27K	18K
C173	0.039	0.022	0.039


☐ FM AUTO NO SIGNAL
() MW NO SIGNAL
[] LW NO SIGNAL



K L M N O P Q R S T



- Notes:
1. — indicates +B power supply.
 2. - - - indicates -B power supply.
 3. ■ indicates main signal path.
 4. ■ indicates recording signal path.
 5. When replacing the parts in the shaded area (■) and those marked with Δ, be sure to use the designated parts to ensure safety.
 6. This is the standard circuit diagram.
 7. The design and contents are subject to change without notice.




(2) Main, Input/Output & Power Amplifier Section (For the versions except Universal and Taiwan)

(B) FOR WITHOUT U, UT


ENH-213-2

IC401
VC-568LD

* MARK	VER.	S. GI	WITHOUT U, UT
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
10	10	10	10
11	11	11	11
12	12	12	12
13	13	13	13
14	14	14	14
15	15	15	15
16	16	16	16
17	17	17	17
18	18	18	18
19	19	19	19
20	20	20	20
21	21	21	21
22	22	22	22
23	23	23	23
24	24	24	24
25	25	25	25
26	26	26	26
27	27	27	27
28	28	28	28
29	29	29	29
30	30	30	30
31	31	31	31
32	32	32	32
33	33	33	33
34	34	34	34
35	35	35	35
36	36	36	36
37	37	37	37
38	38	38	38
39	39	39	39
40	40	40	40
41	41	41	41
42	42	42	42
43	43	43	43
44	44	44	44
45	45	45	45
46	46	46	46
47	47	47	47
48	48	48	48
49	49	49	49
50	50	50	50
51	51	51	51
52	52	52	52
53	53	53	53
54	54	54	54
55	55	55	55
56	56	56	56
57	57	57	57
58	58	58	58
59	59	59	59
60	60	60	60
61	61	61	61
62	62	62	62
63	63	63	63
64	64	64	64
65	65	65	65
66	66	66	66
67	67	67	67
68	68	68	68
69	69	69	69
70	70	70	70
71	71	71	71
72	72	72	72
73	73	73	73
74	74	74	74
75	75	75	75
76	76	76	76
77	77	77	77
78	78	78	78
79	79	79	79
80	80	80	80
81	81	81	81
82	82	82	82
83	83	83	83
84	84	84	84
85	85	85	85
86	86	86	86
87	87	87	87
88	88	88	88
89	89	89	89
90	90	90	90
91	91	91	91
92	92	92	92
93	93	93	93
94	94	94	94
95	95	95	95
96	96	96	96
97	97	97	97
98	98	98	98
99	99	99	99
100	100	100	100




(1) Front Section




- Notes:**
1. ——— indicates +B power supply.
 2. - - - - indicates -B power supply.
 3.  indicates main signal path.
 4. When replacing the parts in the shaded area () and those marked with  , be sure to use the designated parts to ensure safety.
- This is the standard circuit diagram.
5. The design and contents are subject to change without notice.

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z



Schematic Diagram ■ Tuner Section




* MARK

Ver.	C	D	E
R925	1K x 3	NONE	NONE
R927	1K x 3	NONE	NONE
R961	68 x 6	NONE	NONE
R966	68 x 6	NONE	NONE
D891	ISS119	NONE	NONE
D892	ISS119	NONE	NONE
D895	ISS119 x 8	NONE	NONE
D902	ISS119 x 8	NONE	NONE
C921	68P x 6	NONE	NONE
C926	68P x 6	NONE	NONE
P961	USED	NONE	NONE
C984	0.047	0.047	NONE
C887	680P	680P	0.001
C888	680P	680P	0.0018
C889	150P	150P	120P
C891	220	220	180
C892	220	220	180
C901	NONE	NONE	0.012
C902	NONE	NONE	0.012

Notes:

1. — indicates +B power supply.
2. - - - indicates -B power supply.
3. ■ indicates main signal path.
4. When replacing the parts in the shaded are (■) and those marked with △, be sure to use the designated parts to ensure safety.
5. The design and contents are subject to change without notice.

Schematic Diagram



- Notes:**

- Notes:
1. ——— indicates +B power supply
 2. ---- indicates -B power supply.
 3. indicates main signal path.

- When replacing the parts in the shaded are () and those marked with Δ , be sure to use the designated parts to ensure safety.
- The design and contents are subject to change without notice.